



BU 2800 – en

PROFIsafe bus interface

Supplementary manual options for NORD - Frequency Inverters



Table of Contents

1	Introduction	5
1.1	General	5
1.1.1	Documentation	5
1.1.2	Document History	5
1.1.3	Copyright notice.....	5
1.1.4	Publisher	5
1.1.5	About this manual.....	6
1.2	Other applicable documents	6
1.3	Presentation conventions.....	6
1.3.1	Warning information	6
1.3.2	Other information.....	6
1.3.3	Text markings.....	7
1.3.4	List of abbreviations.....	8
1.3.5	Further terminology	9
2	Safety	10
2.1	Intended use	10
2.2	Selection and qualification of personnel.....	10
2.2.1	Qualified personnel.....	10
2.2.2	Qualified electrician	11
2.3	Safety information	11
2.4	Exclusion of liability.....	11
3	PROFINET IO and PROFIsafe principles	12
3.1	Characteristics	12
3.1.1	PROFINET IO.....	12
3.1.2	PROFIsafe.....	14
3.2	Topology	16
3.2.1	Linear topology.....	16
3.2.2	Star topology	17
3.2.3	Ring topology.....	18
3.2.4	Tree topology.....	19
3.3	Bus protocol.....	20
3.3.1	PROFINET IO.....	20
3.3.2	PROFIsafe.....	25
3.4	Description of the function of the PROFIsafe bus interface.....	26
3.4.1	Schematic structure of the PROFIsafe bus interface.....	26
3.4.2	Safe inputs and outputs.....	27
3.4.2.1	Digital inputs	27
3.4.2.2	Digital outputs	28
3.4.2.3	Clock outputs	28
3.4.3	Safety functions.....	29
4	NORD system bus	34
4.1	NORD system bus participants	36
4.2	Access to parameters and control options	37
4.2.1	Access via the NORD SimpleBox.....	37
4.2.2	Access via the NORD ParameterBox.....	37
4.2.3	Access via NORD CON software	38
4.3	Remote maintenance.....	39
5	Initial setup	40
5.1	Connecting the bus interface	40
5.2	Integration into the bus master.....	41
5.2.1	PROFINET IO-Controller.....	41
5.2.2	PROFIsafe F-Host.....	41
5.2.2.1	F-Parameters	41
5.2.2.2	Checksum check (CRC)	41
5.2.3	Installing the device description file	42
5.2.4	Format of process data.....	42
5.3	Addressing the bus interface.....	43
5.3.1	PROFINET IO field bus address.....	43

5.3.2	PROFIsafe - F-Address	44
5.4	Example: Commissioning the PROFIsafe bus module.....	45
6	Data transmission	47
6.1	Introduction	47
6.1.1	Process data.....	47
6.1.2	Parameter data.....	47
6.1.3	F-Data	47
6.2	Structure of application data	48
6.3	Transfer of process data	50
6.3.1	Control word	51
6.3.2	Status word.....	52
6.3.3	Frequency inverter status machine.....	53
6.3.4	Setpoints and actual values.....	57
6.3.5	Process data telegrams.....	59
6.4	Parameter data transmission	61
6.4.1	Structure of acyclic parameter data exchange (Records).....	62
6.4.2	Data records for acyclic parameter orders.....	63
6.4.3	Data record format.....	64
6.4.3.1	Parameter label PKE	64
6.4.3.2	Parameter index IND	67
6.4.3.3	Parameter value PWE	67
6.4.4	Examples of data record transfer.....	68
6.4.4.1	Reading of parameter P717 current speed	68
6.4.4.2	Writing of parameter P102 acceleration time, Index 1	69
6.4.4.3	Telegram structure for parameterisation via PPO1 or PPO2	70
6.5	F-Data transmission.....	71
6.5.1	F-Parameters.....	74
6.5.2	Structure of F-Input and F-Output data.....	75
6.6	Example of setpoint specification	77
7	Parameters.....	78
7.1	Parameter setting on the bus interface	78
7.1.1	NORD standard parameters.....	79
7.1.2	PROFINET IO standard parameters.....	83
7.1.3	NORD information parameters	86
7.1.4	PROFINET IO information parameters.....	91
7.1.5	PROFIsafe standard parameters.....	94
7.1.6	PROFIsafe information parameters	101
7.2	Parameter settings on the frequency inverter	104
8	Error monitoring and error messages.....	106
8.1	Bus operation monitoring function.....	106
8.2	Resetting error messages	108
8.3	Handling of errors in the bus interface	109
8.3.1	PROFINET IO.....	109
8.3.2	PROFIsafe.....	110
8.4	Error messages.....	111
8.4.1	PROFINET IO.....	111
8.4.2	PROFIsafe.....	112
9	Appendix.....	123
9.1	Repair information.....	123
9.2	Service and commissioning information.....	123
9.3	Documents and software	124

List of illustrations

Figure 1: PROFINET IO communication via Application Relation AR	13
Figure 2: Safety data communication	14
Figure 3: Linear topology (example).....	16
Figure 4: Star topology (example)	17
Figure 5: Ring topology (example).....	18
Figure 6: Tree topology (example).....	19
Figure 7: PROFINET IO telegram (communication within a sub-net)	20
Figure 8: PROFINET IO data cycle times	22
Figure 9: PROFIsafe telegrams	25
Figure 10: Bus interface – hardware.....	26
Figure 11: Monitoring of discrepancy time.....	27
Figure 12: Example of the structure of a NORD system bus	34
Figure 13: Remote maintenance via Internet (schematic diagram)	39
Figure 14: Structure of the application data area – Telegram traffic	48
Figure 15: Example – PROFINET IP / PROFIsafe device model for decentralised devices.....	50
Figure 16: Frequency inverter status machine.....	53
Figure 17: Sequence of acyclic PROFINET IO parameter data exchange	62
Figure 18: F-Data exchange	71
Figure 19: Examples of monitoring parameter settings – SK TU4 bus interface.....	107
Figure 20: Flashing code – Error example "5713" (Invalid host address).....	112

1 Introduction

1.1 General

1.1.1 Documentation

Name: **BU 2800**
 Material number **6022802**
 Series: **Field bus system PROFIsafe**

1.1.2 Document History

Edition	Order number	Software version	Remarks
BU 2800 , March 2018	6022802/ 1118	V 1.4 R0	First edition
BU 2800 , April 2018	6022802/ 1618	V 1.4 R0	Minor corrections
BU 2800 , July 2019	6022802/ 3019	PROFINET IO: V 2.0 R5	<ul style="list-style-type: none"> • Minor corrections • Consideration of bus interface SK CU4-PNS
		PROFIsafe: V 1.4 R0	

1.1.3 Copyright notice

As an integral component of the device or the function described here, this document must be provided to all users in a suitable form.

Any editing or amendment or other utilisation of the document is prohibited.

1.1.4 Publisher

Getriebebau NORD GmbH & Co. KG

Getriebebau-Nord-Straße 1
 22941 Bargteheide, Germany

<http://www.nord.com/>

Tel.: +49 (0) 45 32 / 289-0

Fax: +49 (0) 45 32 / 289-2253

1.1.5 About this manual

This manual is intended to assist you in the setup of bus interfaces PROFIsafe from Getriebebau NORD GmbH & Co. KG in a field bus system. It is intended for all qualified electricians who plan, install and set up the field bus system (📖 Section 2.2 "Selection and qualification of personnel"). The information in this manual assumes that the qualified electricians who are entrusted with this work are familiar with the technology of the field bus system and programmable logic controllers (PLC).

This manual only contains information and descriptions of bus interfaces and frequency inverters manufactured by Getriebebau NORD GmbH & Co. KG. It does not contain any descriptions of the controllers and the necessary software for other manufacturers.

1.2 Other applicable documents

This manual is only valid in combination with the Technical Information for the bus interface which is used and the operating instructions for the relevant frequency inverter. Only these documents contain all of the information that is required for safe commissioning of the bus interface module and the frequency inverter. A list of the documents can be found in 📖 Section 9.3 "Documents and software".

The "Technical Information" (TI) for the bus interface and the manuals (BU) for the NORD frequency inverters can be found under www.nord.com.

1.3 Presentation conventions

1.3.1 Warning information

Warning information for the safety of the user and the bus interfaces are indicated as follows:

 DANGER

This warning information warns against personal risks, which may cause severe injury or death.

 WARNING

This warning information warns against personal risks, which may cause severe injury or death.

 CAUTION

This warning information warns against personal risks, which may cause slight or moderate injuries.

NOTICE

This warning warns against damage to material.

1.3.2 Other information

 Information

This information shows hints and important information.

1.3.3 Text markings

The following markings are used to differentiate between various types of information:



Text

Type of information	Example	Marking
Instructions	1st 2nd	Instructions for actions whose sequence must be complied with are numbered sequentially.
Bullet points	•	Bullet points are marked with a dot.
Parameters	P162	Parameters are indicated by the prefix "P", a three-digit number and bold type.
Arrays	[-01])	Arrays are indicated by square brackets.
Factory settings	{ 0,0 }	Factory settings are indicated by curly brackets.
Software descriptions	"Cancel"	Menus, fields, buttons and tabs are indicated by quotation marks and bold type.

Numbers

Type of information	Example	Marking
Binary numbers	100001b	Binary numbers are indicated by the suffix "b"
Hexadecimal numbers	0000h	Hexadecimal numbers are indicated by the suffix "h"

Symbols used

Type of information	Example	Marking
Cross-reference	 Section 4 "NORD system bus"	Internal cross-reference A mouse click on the text calls up the stated point in the document.
	 Supplementary manual	External cross-reference
Hyperlink	http://www.nord.com/	References to external websites are indicated in blue and underlined. A mouse click calls up the website.

Type designations

Designation	Description
SK 1x0E	Series SK 180E frequency inverters
SK 2xxE	Series SK 200E frequency inverters
SK 2x0E-FDS	Series SK 250E-FDS frequency inverters
SK 5xxE	Series SK 500E frequency inverters
SK 54xE	SK 540E and SK 545E frequency inverters

1.3.4 List of abbreviations

Abbreviations used in this manual

Abbreviation	Meaning
AG	Absolute encoder
AK	Order label/response label
AR	Application Relation
BusBG	Bus module
CR	Communication Relation
CRC	Cyclic Redundancy Check, Checksum check
DIN	Digital Input
DIP	Dual In-line Package, Compact switch group
DO	Digital Output
EMC	Electromagnetic compatibility
I / O	Input/Output
F-Device	Failsafe Device, safety device ("F" stands for "functional safety")
F-Data	Safety data
F-Host	Failsafe Host, safety control
F-Parameter	Safety-relevant parameters (for identification, monitoring, etc.), which must be transferred from the IO controller/F-Host to the bus interface
FI	Frequency inverter
GSDML	Generic Station Description Markup Language
HMI	Human Machine Interface
IND	Index
IP	Internet protocol
I/O	Input, Output
i-Parameters	Individual safety parameters of the bus interface
IW	Actual value
OSSD	Output Signal Switching Device, Safety-relevant switch output
PDO	Process Data Object
PKE	Parameter label
PKW	Parameter label value
PNU	Parameter number
PPO	Parameter/Process Data Object
PWE	Parameter value
PZD	Process data
SDI	Safe Direction, drive monitoring which only allows the enabled direction
SDO	Service Data Object
SIL	Safety Integrity Level, safety requirement level (according to IEC 61508/IEC6151)
SLS	Safely Limited Speed, drive monitoring, which triggers an error response (e.g. STO, SS1 etc.) if the speed limit is exceeded
SOS	Safe Operation Stop, drive monitoring which triggers an error response (e.g. STO) if a defined position is departed from
SPI	Serial Peripheral Interface
PLC	Programmable Logical Controller
SS1	Safe Stop 1 (corresponds to Stop Category 1 according to EN 60204), the drive is brought to a standstill in a controlled manner and then STO is activated
SSM	Safe Speed Monitor, drive monitoring in which an error response is triggered by the

Abbreviation	Meaning
	safety controller if a minimum speed is undershot
SSR	Safe Speed Range, combination of SLS and SSM
STO	Safe Torque Off, corresponds to Stop Category 0 according to EN 60204), immediate interruption of the drive power supply, the drive is shut down in an uncontrolled manner
STW	Control word
SW	Setpoint
TCP	Transmission Control Protocol
USS	Universal serial interface
ZSW	Status word

1.3.5 Further terminology

Specific terminology used in this manual:

Term	Meaning
Re-integratable	After acknowledgement of a bus interface error, the bus interface must be re-integrated, i.e. re-connected to the system. Otherwise it cannot be used. For this, the controller must set the command "Acknowledgement for Reintegration" according to the PROFIsafe specification.

2 Safety

2.1 Intended use

PROFIsafe bus interfaces from Getriebebau NORD GmbH & Co. KG are interfaces for PROFINET IO and PROFIsafe field bus communication. These have been developed and configured for use with the following frequency inverters from Getriebebau NORD GmbH & Co. KG.

Bus interface	Frequency inverters
SK TU4-PNS	Series NORDAC <i>FLEX</i> (SK 200E)
SK TU4-PNS-C	
SK TU4-PNT-M12	
SK TU4-PNS-M12-C	
SK CU4-PNS	Series NORDAC <i>LINK</i> (SK 2x0E-FDS)

In addition, it is permissible to use PROFIsafe bus interfaces independent of a frequency inverter as a "stand alone" safety module.

PROFIsafe bus interfaces from Getriebebau NORD GmbH & Co. KG are used for communication by the frequency inverter with a PLC in a PROFINET IO field bus system provided by the operator and with a safety PLC in a PROFIsafe field bus system provided by the operator.

Any other use of the bus interfaces is deemed to be incorrect use.

2.2 Selection and qualification of personnel

The bus interface may only be installed and started up by qualified electricians. These must possess the necessary knowledge with regard to the technology of the field bus system, as well as configuration software and the controller (bus master) which are used.

In addition, the qualified electricians must also be familiar with the installation, commissioning and operation of the bus interfaces and the frequency inverters as well as all of the accident prevention regulations, guidelines and laws which apply at the place of use.

2.2.1 Qualified personnel

Qualified personnel includes persons who due to their specialist training and experience have sufficient knowledge in a specialised area and are familiar with the relevant occupational safety and accident prevention regulations as well as the generally recognised technical rules.


These persons must be authorised to carry out the necessary work by the operator of the system.


2.2.2 Qualified electrician

An electrician is a person who, because of their technical training and experience, has sufficient knowledge with regard to


- Switching on, switching off, isolating, earthing and marking power circuits and devices,
- Proper maintenance and use of protective devices in accordance with defined safety standards.
- Emergency treatment of injured persons.

2.3 Safety information


Only use bus interfaces and frequency inverters from NORD DRIVESYSTEM Group for their intended purpose,  Section 2.1 "Intended use".

To ensure safe operation of the bus interface, observe all of the instructions in this manual, and in particular the warning information in the other applicable documents,  Section 1.2 "Other applicable documents".

Only commission bus interfaces and frequency inverters in their technically unchanged form and not without the necessary covers. Take care that all connections and cables are in good condition.

Work on and with bus interfaces and frequency inverters must only be carried out by qualified personnel,  Section 2.2 "Selection and qualification of personnel".

2.4 Exclusion of liability

This technical documentation is for users who wish to use fail safe modules from Getriebebau NORD GmbH & Co. KG. It is solely for information purposes and is only intended for qualified and adequately trained specialist personnel ( Section 2.2 "Selection and qualification of personnel"). The information provides assistance on the subject of safety technology and was compiled and produced in good faith. No claim is made with regard to the completeness of this documentation, in particular for the listing of directives and standards. The technical and schematic diagrams do not constitute binding solutions or application suggestions for the particular application. The illustrated application examples only relate to modules from Getriebebau NORD GmbH & Co. KG. It is the sole responsibility of the user to check and comply with all laws, directives and standards which are relevant for the particular application, design, manufacture and operation of the products. Users act independently at their own responsibility. Getriebebau NORD GmbH & Co. KG accepts no liability or warranties for solutions which are planned by the user.

3 PROFINET IO and PROFIsafe principles

3.1 Characteristics

3.1.1 PROFINET IO

PROFINET IO is a protocol for communication with peripherals based on the Ethernet standard IEEE 802.3. PROFINET IO is based on PROFIBUS DP and uses Switched-Ethernet technology as the physical communication medium for the rapid communication of I/O data and parameters. PROFINET IO is specified in the standards IEC 61158 and IEC 61784.

In contrast to the PROFIBUS Master-Slave method, PROFINET IO is a Provider-Consumer model, which supports communication relations (CR) between equal field bus participants. In addition to the cyclic exchange of process data, diagnostic data, parameters and alarms can be communicated via the PROFINET IO field bus system.

PROFIBUS® and PROFINET® are registered trademarks of PROFIBUS and PROFINET International (PI).

PROFINET IO bus participants are classified according to their tasks:

Name	PROFINET IO bus participant	Task
IO Controller	Controller (PLC)	Performs the master function for I/O data communication with bus participants and controls the process. As a provider, the IO controller sends the output data to the IO devices and as a consumer it processes the input data which is sent from the IO devices.
IO Device	Decentralised field bus device	As a provider, the IO device sends the input data to the IO controller and as a consumer it processes the output data which is sent from the IO controller.
IO Supervisor	Programming device, HMI or PC	PROFINET IO tool for parameterisation and diagnosis of IO devices, which is only used temporarily for commissioning and diagnosis.

Addressing of PROFINET IO bus participants is carried out via:

- The unique MAC address of the device,
- The unique assigned device name and
- The unique assigned IP address.

For communication between the IO controller and an IO device a so-called "Application Relation" **AR** is established, with which the "Communication Relations" **CR** are specified.




Figure 1: PROFINET IO communication via Application Relation AR


Communication Relation CR	Description
IO data CR	For cyclic communication of process data
Record data CR	For acyclic communication of parameter data
Alarm CR	For alarm messages in real time

Performance description

Standards	IEC 61158, IEC 61784
Possible number of bus participants	Practically unlimited, depending on the number of participants with which the IO controller can communicate.
Transfer rate	100 MBit (Switched Ethernet, Full Duplex)
Update interval	≥ 5 ms (exchange of process data with the frequency inverter)
Conformance Class	B, C
Transmission and reception cable	Auto Crossover, Auto Negotiation, Auto Polarity
Wiring	Standard Ethernet cable CAT 5 or better
Cable length	Max. 100 m between two nodes

Information

Hardware information

Details of the bus interface (technical data and information for assembly and installation) can be found in the documents for the relevant bus interface ( Section 9.3 "Documents and software").

3.1.2 PROFIsafe

PROFIsafe is an additional safety level on the field bus application level (PROFINET IO or PROFIBUS) for the reliable transmission of safety-relevant data, in which communication faults are detected and remedied and safety functions are only triggered if the corresponding faults occur.

PROFIsafe safety data are transferred in the application data of the standard communication (PROFINET IO) independent of the PROFINET IO transmission channel, which is designated as the "Black Channel" below the safety layer.




Figure 2: Safety data communication

PROFIsafe can be used for safety applications up to SIL3 (safety integrity level 3 according to IEC 62061) and is published in Standard IEC 61508.

Performance Level ISO 13849-1	Probability of a hazardous failure per hour	Safety integrity level IEC 62061
a	$10^{-4} \dots 10^{-5}$	—
b	$10^{-5} \dots 3 \times 10^{-6}$	SIL 1
c	$3 \times 10^{-6} \dots 10^{-6}$	SIL 1
d	$10^{-6} \dots 10^{-7}$	SIL 2
e	$10^{-7} \dots 10^{-8}$	SIL 3

In addition to the device requirements of PROFINET IO, PROFIsafe requires the use of a safety controller (F-Host) which ensures the execution of the safety function. The field devices which are used (F-Devices) must support the safety functions.


PROFIsafe® is a registered trademark of PROFIBUS and PROFINET International (PI).

Performance description

Standards	IEC 61508, EN ISO 13849-1
Safety integrity level	Up to SIL 3
Performance Level	e, Cat 4
Processor	Redundant twin processor system
Power supply	From a safely isolated mains unit
Safe digital inputs	2x, with self-test function, two channel operation, configurable
Safe digital outputs	3x, with diagnostic function (OSSD), two channel operation, configurable
Safe clock outputs	2x short circuit-proof, detection of short circuits to the supply voltage detection of short circuits to earth, time-shifted pulsing of both outputs
Safety functions	SLS, SSR, SDI-P, SDI-N, SOS, SSM
Activation and response time	adjustable
Encoders	Input for Sin/Cos encoders
Safety communication	Monitoring of process data, sequential numbering of PROFIsafe telegrams (24-bit counter) and checksum test (CRC), watchdog monitoring

Information

Hardware information

Details of the bus interface (technical data and information for assembly and installation) can be found in the documents for the relevant bus interface( Section 9.3 "Documents and software").

3.2 Topology

The following topologies will be supported:

3.2.1 Linear topology

Linear topology connects bus participants which are equipped with integrated switches.




Figure 3: Linear topology (example)

Advantages: Requires little cable material, can be extended at the end of the line with little effort.

Disadvantages: If the line is interrupted (device failure or defective cable) the downstream bus participants can no longer be accessed.

3.2.2 Star topology

The star topology requires a central switch (in the control cabinet).




Figure 4: Star topology (example)

Advantages: A device failure has no effect on the other bus participants; can be extended with little effort, simple troubleshooting.

Disadvantages: Operation of the network is not possible in case of problems with the switch.

3.2.3 Ring topology

With a ring topology, one line is closed to form a ring for media redundancy.




Figure 5: Ring topology (example)

Advantages: Communication is maintained even in case of a defective cable.

Requirement: Requires Media Redundancy Protocol (MRP).

3.2.4 Tree topology

Linear and star topologies can be mixed in a tree topology.




Figure 6: Tree topology (example)

3.3 Bus protocol

3.3.1 PROFINET IO

The PROFINET IO process data are embedded in standard Ethernet frames. For communication of process data, a PROFINET IO frame is identified with the label "8892h" and a frame ID in the type field "Ethertype".





Figure 7: PROFINET IO telegram (communication within a sub-net)

	Designation	Description
Ethernet Header	DA	Destination Address = Destination address of the PROFINET IO frame
	SA	Source Address = Source address of the PROFINET IO frame
	VLAN Tag	Identifier for communicating the priority
	8892h	Ethertype identifier
PROFINET IO	Frame ID	Data identifier for cyclic or acyclic communication
	Status	Status information
Ethernet	FCS	Checksum of the PROFINET IO frame

PROFINET IO is subdivided into various performance classes, the so-called "Conformance Classes" CC-A, CC-B and CC-C.

Conformance Class	Description
CC-A	<ul style="list-style-type: none"> • Cyclic exchange of I/O data with real time characteristics • Acyclic data exchange for reading and writing of parameters and diagnostic data, including the function Identification & Maintenance I&M for reading out device information • Alarm function for signalling device and network faults in three levels (maintenance requirement, urgent maintenance requirement, diagnosis)
CC-B	<ul style="list-style-type: none"> • Cyclic exchange of I/O data with real time characteristics • Acyclic data exchange for reading and writing of parameters and diagnostic data, including the function Identification & Maintenance I&M for reading out device information • Alarm function for signalling device and network faults in three levels (maintenance requirement, urgent maintenance requirement, diagnosis) • Network diagnosis with the Simple Network Management Protocol (SNMP) • Topology detection with the Link Layer Discovery Protocol (LLDP)
CC-C	<ul style="list-style-type: none"> • Cyclic exchange of I/O data with the Isochronous Real Time Protocol • Acyclic data exchange for reading and writing of parameters and diagnostic data, including the function Identification & Maintenance I&M for reading out device information • Alarm function for signalling device and network faults in three levels (maintenance requirement, urgent maintenance requirement, diagnosis) • Network diagnosis with the Simple Network Management Protocol (SNMP) • Topology detection with the Link Layer Discovery Protocol (LLDP) • Reservation of bandwidth: Part of the available communication bandwidth of 100 MBit is exclusively reserved for real time tasks • Synchronisation of the application program clock to the bus cycle

The process data are communicated cyclically from the IO controller to the IO devices in real time and inversely from the IO devices into the process image of the IO controller. As the IO controller transfers the data without a request, when the system is started up, the IO devices are informed that they will receive current data in a particular bus cycle.



¹⁾ See Information RT, IRT

Figure 8: PROFINET IO data cycle times

Item	Description
1	Standard communication (IT services, TCP/IP)
2	Process automation
3	Motion Control (drive control)
TCP/IP	Internet protocol, cycle time less than 100 ms
RT	Real time protocol, cycle time less than 10 ms
IRT	Isochronous real time protocol, cycle time 0.25 ms...1.0 ms
System bus	NORD-specific bus system between the bus interface and frequency inverters, cycle time ≥ 5 ms
Safety function	Safe communication path between PROFIsafe bus interface and frequency inverter or encoder

i Information

RT, IRT

The NORD PROFINET IO bus interfaces communicate exclusively via RT communication, while the Ethernet switches in the modules are IRT capable.

PROFINET IO real time communication is divided into the following classes:

RT class	Description
RT_CLASS_1	Unsynchronised real time communication within a sub-network (identical to network ID) Unsynchronised RT communication is the normal form of PROFINET IO data communication and is implemented in all IO field devices. Industrial standard switches can be used in this RT class. Suitable for typical cycle times of 10 ms.
RT_CLASS_2 (IRT Flex)	RT_CLASS_2 frames can be communicated either synchronised or unsynchronised. With synchronised communication the start of a bus cycle is defined for all participants. This defines precisely when a field device may transmit. This is always the start of the bus cycle (clock synchronisation) for all field devices involved in RT_CLASS_2 communication. Combination with RT_Class_1 is possible.
RT_CLASS_3 (IRT or IRT Top)	Synchronised communication within a sub-net. Transmission of process data takes place in a sequence which is specified by the system engineering. This optimised data communication requires considerable planning effort, special hardware and the use of real time switches. Suitable for cycle times of 0.25 ms...1 ms.
RT_CLASS_UDP	Unsynchronised data exchange of UDP data packages between different sub-nets. Suitable for the communication of PROFINET IO data which are not time-critical. This RT communication (Transport Protocol TCP/UDP-ID) can be implemented with all standard network components (e.g. Internet, company Intranet, etc.) Data cycles of 5 ms with 100 Mbit/s can be achieved in Full Duplex mode.

3.1 "Characteristics"

Performance description of NORD-PROFINET bus interfaces  Section .

Details of communication sequence

PROFINET IO works on the basis of real time communication (RT). IT is therefore possible to configure the bus system so that in addition to RT communication, isochronous real time communication (IRT) is possible, which is especially important for time-sensitive procedures such as for Motion Control applications. With a corresponding configuration of an IO controller, communication in PROFINET IO operates in two phases, the IRT phase and the open phase.

The IRT phase is exclusively reserved for IRT frames. In the course of planning, the user precisely specifies the sequence in which the participants transmit. Communication between the participants is carried out synchronously. Any accumulating RT frames or UDP/IP frames are temporarily saved in the switches without processing In this way, the IRT frames can be transferred to the IO controller without waiting times. The resulting telegraph run time for the IRT frames ultimately depends on the number of switches which are integrated into the communication line and their throughput times.

In the open phase, which is defined by the IO controller, the temporarily stored RT or UDP/IP frames are transferred. However, a destination port can only receive one frame at a time from the switch. Further frames which are intended for this destination port are temporarily saved in the switch. Depending on the structure or the setup of the communication line, there may be a delay in the exchange of information during the open phase.

This means that with isochronous real time communication (IRT) the run times for messages between the devices and the IO controller are always identical; in contrast, for real time communication (RT) they depend on the bus load and are therefore different in each cycle. The difference between RT and IRT communication therefore does not lie in the performance of the individual components, but rather in the limitations due to the extension of the communication line.

SK CU4-PNT, SK TU4-PNT and SK TU3-PNT PROFINET IO bus interfaces as well as SK TU4-PNS PROFIsafe bus interfaces are each equipped with an integrated switch with two ports for setting up a linear topology. The integrated switches support synchronised RT_Class_3 communication, however the bus interfaces only use RT_Class_1 communication.

Therefore, IRT field devices which are physically arranged behind a NORD PROFINET IO bus interface can also participate in IRT communication.

The PROFINET IO bus interface participates in the standard RT communication. The smallest interval which can be set, in which data from the bus interface are transmitted without synchronisation to the IO controller, and in which this data can be received is 1 ms.

Communication between the bus interface and the relevant NORD drive components is via the NORD system bus. The required communication time is added to the run time for PROFINET IO communication.

The specific values for the update interval for process data, parameter reading and writing access can be obtained from the data sheets (TIs) for the relevant bus interfaces.

3.3.2 PROFI-safe

A PROFI-safe telegram which is to be transmitted is included in the PROFINET IO application data. Either up to 12 bytes of the input and output data are used – in which case a CRC of 3 bytes is used – or 13 to 123 bytes of the input and output data are used – in which case a 4 byte CRC is used. Getriebebau NORD GmbH & Co. KG uses 4 byte input and output data and therefore uses the 3 byte CRC.




Figure 9: PROFI-safe telegrams

The data frame is supplemented with a control byte (CB = Control Byte) or a status byte (SB = Status Byte). The data package is secured with a checksum (CRC). The length of this checksum is 3 or 4 bytes, depending on the amount of data to be transferred.

See  Section 6 "Data transmission" for detailed information.

3.4 Description of the function of the PROFIsafe bus interface

The PROFIsafe bus interface monitors the safe compliance with the limit values and provides safe inputs and outputs. If a limit value is exceeded or undershot, the bus interface switches to a safe state. The voltage is disconnected from all outputs, input information is reset and transmitted to the higher level PROFIsafe controller (F-Host).

3.4.1 Schematic structure of the PROFIsafe bus interface

PROFINET IO/PROFIsafe




Figure 10: Bus interface – hardware

Communication between the PROFINET IO and the PROFIsafe PCB is via the SPI interface. The safety-relevant data telegrams are transmitted to one of the two SAFE micro-controllers (μC 1 or μC 2) via the so-called "Black Channel". The two micro-controllers are synchronised via the second free SPI channel.

3.4.2 Safe inputs and outputs

3.4.2.1 Digital inputs

The bus interface has two safe single channel digital inputs, which are combined to form a two-channel input (parameter **P800 Operating mode I/O**) The input circuit is reverse polarity protected and is redundantly structured with self-monitoring. There is no monitoring of the pulse pattern from the clock output. Incorrect connection (clock Output 1 to Input 2 and vice versa) is therefore not detected. Only the clock outputs detect a short circuit.

Two channel operation is monitored with an adjustable discrepancy time (parameter **P803 Discrepancy time**)




Figure 11: Monitoring of discrepancy time

Item	Meaning
A	Error-free input signal
B	Incorrect input signal
SIA	Safe input, Channel A
SIB	Safe input, Channel B
R	Internal evaluation of safe input
D	Discrepancy monitoring
ACK	Fault acknowledgement
1	Discrepancy monitoring enabled
2	Set discrepancy time exceeded
3	Error acknowledgement not permissible
4	Error acknowledgement permissible

3.4.2.2 Digital outputs

The bus interface is equipped with three safe digital outputs (max. output current 0.3 A each):

- Safety-relevant switch output OSSD1 and OSSD2, redundant with self-monitoring.
- Periodic testing of outputs with switch-off test (test pulses).
- The two single channel outputs SO1 and SO2 can be combined to form a two channel output (Parameter **P800 operating mode I/O**).
- "P" switching output circuit (i.e. the GND line is not switched).

3.4.2.3 Clock outputs

The bus interface is equipped with two safe clock outputs, which are used for the monitored 24V power supply of the connected devices (e.g. passive sensors such as EMERGENCY STOP switches). The clock outputs are short circuit-proof. In order to detect cross short-circuits, the clock outputs are pulsed with a time shift. Short circuits to the supply voltage and earthing faults are detected. The inputs do not perform diagnosis of the pulse pattern of the clock outputs. Incorrect connection (clock Output 1 to Input 2 and vice versa) is therefore not detected. Only the clock outputs detect a short circuit.

3.4.3 Safety functions

i Information

Fail safe encoder

The safety functions described below require the **mandatory** use of a fail safe encoder.


i Information


Use of safety functions


In order to be able to use the following safety functions SLS, SSR, SDI and SOS, this must also be enabled by the safety PLC via the F-Data. An error is triggered if a safety function is enabled without it having been switched on.


The bus interface supports the following safety functions (drive safety functions according to EN IEC 61800-5-2:2007). Selection and setting of the safety functions is made with the parameters **P820...P824** (📖 Section 7.1.5 "PROFIsafe standard parameters")


For specialists, the English names are normally used for identification, even in the German-speaking area.

SLS	Safely Limited Speed
Description	The bus interface monitors compliance with the set limited speed of the drive. If the speed limit is exceeded, an appropriate error response is triggered (triggering of the safety function).
Function	<p>The value of the speed is monitored.</p> 
Error response	If the speed exceeds the speed limit which is set, an error message is transmitted to the controller via the F-Data (safety data). If passivation of the module is set as the fault response (parameter P801 Fault response) the bus interface goes into the fail safe condition. The bus interface can be re-integrated when 10 seconds have elapsed after the triggering of the fault.
Parameters	P820 Safety function, P821 Activation time, P822 Response time, P823 Speed limit

SSR	Safe Speed Range
Description	The bus interface monitors compliance with the set limited speed range of the drive. If the speed limit is exceeded or undershot an appropriate error response is triggered (triggering of the safety function).
Function	The value of the speed is monitored. <div style="text-align: center;">  <p>The graph illustrates the monitoring of speed (v) over time (t). A yellow shaded region represents the Safe Speed Range (SSR), bounded by two horizontal lines. A red line represents the actual speed of the drive. At time t₁, the speed drops below the lower limit of the SSR. At time t₂, the speed rises above the upper limit of the SSR. The area between the red line and the SSR boundaries is shaded blue, indicating the period of non-compliance.</p> </div>
Error response	If the speed exceeds or undershoots the speed range which is set, an error message is transmitted to the controller via the F-Data (safety data). If passivation of the module is set as the fault response (parameter P801 Fault response) the bus interface goes into the fail safe condition. When 10 seconds have elapsed after the triggering of the fault, the bus interface can be re-integrated.
Parameters	P820 Safety function, P821 Activation time, P822 Response time, P823 Speed limit

SDI-P, SDI-N	Safe Direction, positive, negative (safe direction of movement)
Description	The bus interface monitors compliance with the set direction of movement. If an incorrect direction is detected, an appropriate error response is triggered (triggering of the safety function).
Function	<p>The direction of movement is monitored.</p> 
Error response	If an incorrect direction of movement is detected, an error message is transmitted to the controller via the F-Data (safety data). If passivation of the module is set as the fault response (parameter P801 Fault response) the bus interface goes into the fail safe condition. The bus interface can be re-integrated when 10 seconds have elapsed after the triggering of the fault.
Parameters	P820 Safety function, P821 Activation time, P822 Response time, P824 Max. position error
Note	With parameter P824 Max. position error a permissible position deviation can be set for this safety function.

SOS	Safe Operating Stop
Description	The bus interface monitors compliance with a position within a defined range. If the range is exceeded, an appropriate error response is triggered (triggering of the safety function).
Function	<p>The position is monitored.</p> 
Error response	If the set position range is exceeded, an error message is transmitted to the controller via the F-Data (safety data). If passivation of the module is set as the fault response (parameter P801 Fault response) the bus interface goes into the fail safe condition. The bus interface can be re-integrated when 10 seconds have elapsed after the triggering of the fault.
Parameters	P820 Safety function, P821 Activation time, P824 Max. Position error

SSM	Safe Speed Monitor
Description	The bus interface monitors compliance with the minimum speed. If the speed limit is exceeded, an appropriate error response is triggered (triggering of the safety function).
Function	<p>The value of the speed is monitored.</p>  <p>The graph illustrates the speed monitoring function. The vertical axis is labeled 'v' (speed) and the horizontal axis is labeled 't' (time). A red line represents the speed profile, which starts at a constant level, then drops to a lower level between two time points, t_1 and t_2, indicated by vertical dashed lines. The area between the red line and a horizontal line representing the speed limit is shaded yellow and labeled 'SSM'. The area below the speed limit line is shaded blue.</p>
Error response	<p>If the set speed limit is exceeded, an error message is transmitted to the controller via the F-Data (safety data). Even if passivation of the module is set as the fault response (parameter P801 Fault response) the bus interface does NOT go into the fail safe condition.</p>
Parameters	P822 Response time, P823 Speed limit
Note	The safety function SSM is permanently enabled.

4 NORD system bus

Communication between the bus interface and frequency inverters from Getriebebau NORD GmbH & Co. KG is carried out via a separate NORD system bus. The NORD system bus is a CAN field bus; communication is via the CANopen protocol.

One or more frequency inverters in the field bus system can be accessed via a bus interface.




Figure 12: Example of the structure of a NORD system bus

Item	Description
1	NORD system bus (CAN field bus)
2	SK TU4 bus interface
3	Frequency inverter
4	Absolute encoder
5	Input/output extension SK TU4-IOE
6	NORD CON computer (on Windows® based PC, on which the NORD CON parameterisation and control software is installed)
7	Field bus

i Information

Fail safe communication

There is **no** fail safe communication via the system bus. Fail safe communication is carried out exclusively via the corresponding IOs (safe inputs/safe outputs).

Due to the maximum permissible current capacity of the safe outputs of the bus interface, just one safe input (STO) of a frequency inverter can be controlled by each safe output.


From this, the following application options result for **SK TU4-PNS-...** fail safe bus interfaces:

- Control of the safe input (STO) of a frequency inverter by a safe output (SO1 or SO2 or SO3) of the bus interface. Therefore, up to 3 frequency inverters can be safely controlled by a bus interface.
 - Evaluation of a safe encoder for safe speed monitoring by the bus interface and control of the safe input (STO) of a frequency inverter by a safe output (SO1 or SO2 or SO3) of the bus interface. Therefore, up to 3 frequency inverters can be safely controlled by a bus interface.
 - Evaluation of a safe encoder for speed control by the frequency inverter and for safe speed monitoring by the bus interface. Therefore, just one frequency inverter can be safely controlled by a bus interface.
-

4.1 NORD system bus participants

Possible number of bus nodes on a system bus:

	Decentralised frequency inverters		Central frequency inverters	
	SK 1x0E	SK 2xxE	SK 500–535E	SK 54xE
Frequency inverter	4	4	—	—
Input/output extensions	8	8	—	16
CANopen encoder	4	4	—	—
Bus interface	1	1	1	1
NORD CON computer	1	1	1	1


All participants on the NORD system bus must be assigned a unique address (CAN ID). The address of the bus interface is pre-set at the factory and cannot be changed. Connected IO extensions must be assigned to the frequency inverters ( Technical Information/Data Sheet of the relevant IO extension). Depending on the device, the addresses of the frequency inverter and the connected absolute encoder can be set via the parameter **P515 CAN address** or via the DIP switches.

If absolute encoders are used, these must be assigned directly to a frequency inverter. This is carried out using the following equation:

Absolute encoder address = CAN ID of the frequency inverter + 1


This results in the following matrix:

Device	FI 1	AG1	FI 2	AG2	...
CAN-ID	32	33	34	35	...


The termination resistor must be activated on the first and last participant in the system bus ( Frequency inverter manual) The bus speed of the frequency inverter must be set to "250 kBaud" (**P514 CAN baud rate**) This also applies to any absolute encoders which are connected.

Information

SK 5xxE series, SK 511E and above

Setup of a system bus with SK 5xxE series devices is only possible for SK 511E devices and above and is made via their RJ45 sockets. It must be noted that the RJ45 sockets must have a 24 V DC supply in order to enable communication via the system bus ( Frequency inverter manual).

4.2 Access to parameters and control options

Communication by NORD control devices (SimpleBox and ParameterBox) and the NORD CON software with the bus interfaces and the frequency inverters on the NORD system bus is carried out via the USS protocol ( Manual [BU 0050](#))




Information

Access to bus interface parameters

- Access to bus interface parameters is only possible via the NORD CON software or the ParameterBox, not however via the SimpleBox (SK CSX-3...).
- Access to the parameters of a SK TU4 is possible via the NORD system bus by connection to a frequency inverter or also directly by connection to the RJ12 interface of the SK TU4.
- Access to the parameters of a SK CU4 is only possible via the NORD system bus (CANopen) by connection to a frequency inverter.

4.2.1 Access via the NORD SimpleBox

By connection of the SimpleBox ( Manual [BU 0040](#)) to a frequency inverter a **point-to-point USS bus communication** is established. The SimpleBox only communicates with the frequency inverter to which it is connected.

4.2.2 Access via the NORD ParameterBox

Access via the ParameterBox ( Manual [BU 0040](#)) can be obtained by several methods:

- Connection of the ParameterBox to a frequency inverter for **point-to-point USS bus communication**. The ParameterBox only communicates with the frequency inverter to which it is connected.
- Connection of the ParameterBox to a frequency inverter for **USS communication** with a maximum of 6 participants (5 devices plus ParameterBox). This requires an installed USS bus:
 - Wired,
 - Termination resistors set,
 - USS bus participants addressed.
- Connection of the ParameterBox to a bus interface or frequency inverter for **system bus communication (CANopen)** with a maximum of 6 participants (5 devices plus ParameterBox).

This requires an installed system bus:

- Wired,
- Termination resistors set,
- System bus participants addressed, USS addresses set to the factory setting ("0"). If the ParameterBox detects an active system bus, a USS address is automatically assigned to all of the participants which are detected.

Communication is via the USS protocol. The CANopen interface of the bus interface or the device with which the ParameterBox is connected acts as a gateway.

4.2.3 Access via NORD CON software

Access via the NORD CON software ( Manual [BU 0000](#)) can be obtained by several methods:

- Connection of the NORD CON computer to a frequency inverter for **point-to-point USS bus communication**. The NORD CON software only communicates with the frequency inverter to which it is connected.
- Connection of the NORD CON computer to a frequency inverter for **USS communication** with a maximum of 32 participants (31 devices plus ParameterBox). This requires an installed USS bus:
 - Wired,
 - Termination resistors set (only for RS485 connection. This is not necessary for an RS232 connection).



Information

USS address

It is not necessary to set a USS address.

- Connection of the NORD CON computer to a bus interface or frequency inverter for **system bus communication (CANopen)** with a maximum of 32 participants (31 devices plus NORD CON). This requires an installed system bus:
 - Wired,
 - Termination resistors set,
 - System bus participants addressed, USS addresses set to the factory setting ("0"). If the NORD CON software detects an active system bus, a USS address is automatically assigned to all of the participants which are detected.

Communication is via the USS protocol. The CANopen interface of the bus interface or the device with which the NORD CON software is connected acts as a gateway.

4.3 Remote maintenance

NORD bus interfaces are designed for remote maintenance via the field bus system. Devices which are connected to the bus interface and the NORD system bus (frequency inverters, I/O extensions) from Getriebebau NORD GmbH & Co. KG can also be accessed via LAN or Internet for maintenance purposes.






Figure 13: Remote maintenance via Internet (schematic diagram)

Item	Description
1	NORD CON software
2	Modem
3	LAN
4	Field bus gateway or bus master (PLC)
5	Field bus
6	Bus interface
7	NORD system bus
8	NORD- frequency inverter

5 Initial setup

The bus interface must be set up in order to commission the field bus system. This consists of the following work:

Type of work	Description 
Connect the bus interface to the frequency inverter	Section 5.1 "Connecting the bus interface"
Configure the control project	Section 5.2 "Integration into the bus master"
Assign the bus address	Section 5.3 "Addressing the bus interface"
Make the required parameter settings	Section 7 "Parameters"

An example of the procedure for setting up the field bus system can be found at the end of this section ( Section 5.4 "Example: Commissioning the PROFIsafe bus module").


Detailed information about EMC compliant installation can be found in the Technical Information [TI 80_0011](#) under www.nord.com

5.1 Connecting the bus interface



Information

F-Address via DIP switch

The F-Address is exclusively set with the DIP switches of the bus interface (refer to the Technical Information/ Data Sheet for the bus interface, and  Section 5.3 "Addressing the bus interface").


Connection of the bus interface to the frequency inverter and the PROFINET IO-/PROFIsafe field bus is described in the relevant technical information:

Bus interface	Frequency inverters	Documentation
SK TU4-PNS	Series NORDAC FLEX (SK 200E)	Technical Information/Data Sheet TI 275281116
SK TU4-PNS-C		Technical Information/Data Sheet TI 275281166
SK TU4-PNS-M12		Technical Information/Data Sheet TI 275281216
SK TU4-PNS-M12-C		Technical Information/Data Sheet TI 275281266


5.2 Integration into the bus master



5.2.1 PROFINET IO-Controller

The bus master must first be configured for communication with the bus interface (PLC project for the IO controller). The configuration must be produced with a software system for PROFINET IO field bus systems (e.g. "Simatic Step 7" from Siemens AG).


For integration of NORD frequency inverters into the Siemens AG SIMATIC Manager, Getriebebau NORD GmbH & Co. KG provides standard S7 modules, which can be used for both PROFINET IO as well as for PROFIBUS field bus systems ( Manual [BU 0940](#)).

5.2.2 PROFIsafe F-Host


The PROFIsafe safety controller (F-Host) must specify the basic communication parameters for the PROFIsafe communication for the exchange of safety-relevant data with the bus interface. This is done by setting the so-called "F-parameters" which are read in with the NORD device description file ( Section 5.2.3 "Device description file installation").

In addition, a checksum check (CRC) for the so-called "i-parameters" (PROFIsafe standard parameters for the bus interface, ( Section 7.1.5 "PROFIsafe standard parameters")) must be configured in the safety PLC. If the calculated checksum does not match the checksum which is calculated by the NORD CON software, an error is triggered ( Section 8 "Error monitoring and error messages")

5.2.2.1 F-Parameters

Detailed description of the F-Parameters and the F-Parameter telegram structure ( Section 6.5 "F-Data transmission")

5.2.2.2 Checksum check (CRC)

After setting the i-parameters with the NORD CON software, the checksum of the i-Parameters must be read out and transmitted to the safety controller. Readout of the checksum is carried out with parameter **P840 I-Para CRC**, transmission of the value to the bus interface is carried out via parameter **P830 Save I-Para** ( Section 7.1.5 "PROFIsafe standard parameters").

5.2.3 Installing the device description file


The functionality and the device characteristics of the bus interface are described in a device description file (GSDML file). This file contains all the relevant data which are of importance for both the engineering and the exchange of data with the bus interface.

The current device description file can be obtained from our website www.nord.com directly from the link [Fieldbus Files](#) by selecting the "PROFINET" option.

Sequence

1. Install the GSDML file in the configuration software.
2. Create the hardware configuration (project) in the configuration software.
3. Drag (insert) the required bus interface into the project from the hardware catalogue.
 - After insertion of each individual bus interface the frequency inverter **F11** is planned.
 - If several frequency inverters are used, this must be configured in the configuration software. For this, the corresponding modules must be dragged from the hardware catalogue into the slots of the planned hardware configuration.

5.2.4 Format of process data

For the cyclic transfer of process data for the bus interface and the frequency inverter, the data format must be specified in the configuration project. For detailed information about process data, please refer to ( Section 6.3 "Transfer of process data").

5.3 Addressing the bus interface

In order for the bus interface and the connected frequency inverters to be detected by the IO and the F-Host, an IP address and a device name (PROFINET IO) as well as an F-Address (PROFIsafe) must be assigned to the bus interface. The settings must be made in both the operator's PROFINET IO and PROFIsafe configuration software as well as in the NORD CON software.

5.3.1 PROFINET IO field bus address

The following bus interface parameters are relevant for establishing communication via PROFINET IO:

- **P160 IP address**
- **P161 IP sub-net mask**
- **P162 Device name**
- **P164 IP gateway** (if the gateway function is configured)

Only the assignment of the device name (**P162**) by the commissioner is necessary. Assignment of the IP address data (**P160, P161, P164**) is normally carried out automatically by the IO controller.

Requirement

- The PROFINET IO field bus system has been installed and commissioned according to the manufacturer's instructions.
- Access to the bus interface parameters is possible (a ParameterBox ([BU 0040](#)) or a NORD CON computer are available ([BU 0000](#))).

Procedure

1. Assign a device name, an IP address and a sub-net mask and if necessary activate the gateway function in the PROFINET IO configuration software for the bus master of the bus interface.
2. With the aid of the ParameterBox or the NORD CON software, call up the parameter **P162 Device name** of the bus interface, enter the device name and save this.

Information

In order for the bus interface to be detected when the IO controller is started up, the device name which is entered here must conform with the device name which is assigned in the PLC project.

Observe the following conventions when entering the device name:

- The device name may have a maximum of 127 characters. Lower case letters a..z, numbers 0..9, hyphens /- and fullstops "." are permissible.
 - A character string between two hyphens or two full stops may only have a maximum length of 63 characters.
 - The device name must not contain any special characters (umlauts, brackets, slashes and underscores etc.) or spaces.
 - The device name must not begin or end with a hyphen.
 - The device name must not begin or end with a number.
 - The device name must not have the format "n.n.n.n" or start with the character sequence "port-*nnn*" (*n* = 0..9).
-

In addition, the IP address data can be parameterised in the bus interface as follows:

3. With the aid of the ParameterBox or the NORD CON - software, call up the parameter **P160 IP address** of the bus interface, enter the IP address and save this.

i Information

If the IP address of the bus interface has been configured in the PLC project, this is automatically assigned to the bus interface when the IO controller is started up. Parameter **P160** is then set to "0". In this case, the currently set IP address can be obtained via parameter **P185**.

If the IP address which is entered does not conform with the IP sub-net mask which is entered in parameter **P161** the IP sub-net mask is corrected automatically.

4. Enter parameter **P161 IP subnet mask**, enter the IP subnet mask and save.
-

i Information

If the IP sub-net mask has been configured in the PLC project, this is automatically assigned to the bus interface when the IO controller is started up. Parameter **P161** is then set to "0". In this case, the currently set IP sub-net mask can be obtained via parameter **P186**.

The IP sub-net mask is only saved after a value is entered in Array [-04].

If the IP sub-net mask does not conform with the IP address which is entered in **P160** the entry is not saved.

5. Enter Parameter **P164 IP gateway**, enter the IP address for the gateway function and save.
-

i Information

If the IP address for the gateway function has been configured in the PLC project, this is automatically assigned to the bus interface when the IO controller is started up. This parameter is then set to "0". In this case, the currently set IP address can be obtained via parameter **P187**.

5.3.2 PROFIsafe - F-Address

To ensure that safety relevant components have a unique communication relationship, an F-Address must be assigned to the PROFIsafe bus interface. This address is not a typical field bus address, but rather a code name for the unique identification of the device.

To transfer safety relevant data, with each data package, the bus interface transmits the F-Address, which is checked by the F-Host (comparison via F-Parameters). The cyclic exchange of the safe process data is only started if the matching data set for the F-Address has been received.


Setting of the F-Address is made via DIP switches( Technical Information/Data Sheet).

i Information

F-Parameter "F_Dest_Add"

The F-Address which is set with the DIP switch must agree with the value of the F-Parameter "F_Dest_Add" in the configuration project of the F-Host.

The F-Address is read in by the bus interface when the bus interface is connected to the power supply ("POWER ON").

The F-Address which is set can be read out via the parameter **P846 DIP switch status** ( Section 7.1.6 "PROFIsafe information parameters").

5.4 Example: Commissioning the PROFIsafe bus module



The following example contains an overview of the necessary steps for commissioning the bus interface in a PROFINET IO / PROFIsafe field bus system. The example does not include any details of application-specific settings (motor data, control parameters, etc.).








Example:

Via a bus interface, 3 frequency inverters are to be independently controlled in positioning operation with a single speed and a single position specification.

Device type	Name	Connected motor	Characteristics
Bus interface SK TU4-PNS	BusBG ¹		
SK 2x5E frequency inverter	FI 1	4-pole/n=1390 rpm/50 Hz	Motor with CANopen absolute encoder AG1
SK 2x5E frequency inverter	FI 2	4-pole/n=1390 rpm/50 Hz	Motor with CANopen absolute encoder AG2
SK 2x5E frequency inverter	FI3 ¹	4-pole/n=1390 rpm/50 Hz	Motor with CANopen absolute encoder AG3

¹ The bus interface and frequency inverter FI3 are physically the last participants on the NORD system bus.

Communication	Step	Explanation	
PROFIsafe	1	Set the F-Address for safe communication with the F-Host.	
NORD system bus	2	Set the termination resistors.	
		Set DIP switch 1 (of 12) on the bus interface to the "ON" position.	
		Set DIP switch S2 on frequency inverter FI3 to the "ON" position.	
			All other DIP switches (termination resistors) must be in the "OFF" position.
	3	Set up system bus.	A 24 V supply is required! ( Technical Information for the bus interface)
	4	Set the system bus address of the frequency inverter	Preferably with the DIP switches ( BU 0200):
			FI1 Address "32"
			FI2 Address "34"
			FI3 Address "36"
			AG1 Address "33"
AG2 Address "35"			
		AG3 Address "37"	
		The address of the bus interface is pre-set and cannot be changed.	
5	Set the system bus baud rate.	Set "250 kBaud" on FI 1 to FI 3 as well as on AG 1 to AG 3.	
6	Set the parameters for system bus communication.	Set the following parameters on each frequency inverter:	
		P509 3 (system bus)	
		P510, [-01] 0 (Auto)	
		P510, [-02] 0 (Auto)	
		P543, [-01] 1 (actual frequency)	
		P543, [-02] 10 (actual position incl.Low word)	

Communication	Step	Explanation
		P543 , [-03] 15 (actual position incl. High world) P546 , [-01] 1 (setpoint frequency) P546 , [-02] 23 (setpoint frequency incl.Low word) P546 , [-03] 24 (setpoint frequency incl. High word)
PROFINET IO and PROFIsafe	7	Set up the bus interface for field bus communication.  Sections 5.1 "Connecting the bus interface" to 5.3 "Addressing the bus interface"
PROFINET IO	8	Set the following parameters on the bus interface ( Section 7.1.1 "NORD standard parameters"): P151 200 ms (Timeout external bus)
PROFIsafe	9	Set up the bus interface for safe field bus communication.  Section 7.1.5 "PROFIsafe standard parameters"): P800...P830
NORD system bus	10	Set the parameters for system bus monitoring.  BU 0200): P120 , [-01] 1 (Auto) or 2 (monitoring active immediately)
	11	Check the system bus communication.  BU 0200): P748 "System bus status" P740 , [-01] "Control word" (047Eh = Ready for switch-on) P740 , [-02] "Setpoint 1" P741 , [-01] "Status word" (0B31h = Ready for switch-on) P741 , [-02] "Actual value 1"  Section 7.1.3 "NORD information parameters"): P173 "Module status"
PROFINET IO	12	Check the field bus communication.  Section 7.1.3 "NORD information parameters"): P173 "Module status" P740 "Process data Bus In" P177 "Process data Bus Out"

6 Data transmission

6.1 Introduction

With the data communication between the frequency inverter (via the bus interface) and the bus master (PLC) process data and parameter data as well as safety -relevant data (F-Data) are exchanged.

The F-Data are transmitted in the application data of the PROFINET IO communication, independent from the PROFINET IO channel.

6.1.1 Process data

- Process data are the control word and up to 3 setpoints, as well as the status word and up to 3 actual values. Control words and setpoints are communicated from the bus master to the frequency inverters. Status words and actual values are communicated from the frequency inverters to the bus master.
- Process data are necessary to control the frequency inverter.
- The transfer of process data is carried out cyclically with priority between the bus master and the frequency inverters.
- In the PLC the process data are stored directly in the I/O area.
- Process data are not saved in the frequency inverter.

📖 Section 6.3 "Transfer of process data".

6.1.2 Parameter data

- Parameter data are the setting values and device data for the bus interface and the connected frequency inverter.
- Transfer of the parameter data is carried out acyclically without priority.
- If PPO types 1 and 2 are used (📖 Section 6.3.5 "Process data telegrams") the parameters can be transferred cyclically.

📖 Section 6.4 "Parameter data transmission".

6.1.3 F-Data

- F-Data (safety data) are process and parameter data of the bus interface and the connected frequency inverter, which are transmitted in order to comply with the limit values and trigger application-related safety functions.
- The exchange of F-Data is performed cyclically with priority, or as necessary (due to an event), between the safety controller (F-Host) and the bus interface (F-Device).

📖 Section 6.5 "F-Data transmission".

6.2 Structure of application data

The cyclic exchange of application data between the IO controller and the frequency inverter or the safety controller (F-Host) is carried out via two areas:

- PKW area = **Parameter Label Value** (parameter level)
- PZD area = **ProcessData** (process data level)

The PROFIsafe safety data are included in the PROFINET IO application data and transmitted via a separate channel ("Black Channel" principle).

Parameter values can be read and written via the PKW area. These are essentially configuration, monitoring and diagnostic tasks.

The frequency inverter is controlled via the PZD area. This is done by transfer of the control word, the status word and by setpoint and actual values.

An access always consists of an order and a response telegram. In the order telegram, the application data from the IO controller/F-Host are transferred to the IO device/F-Device. In the response telegram, the application data is transferred from the IO device/F-Device to the IO controller/F-Host.




Figure 14: Structure of the application data area – Telegram traffic

Item	Meaning
A	Order telegram
1	Parameter order
2	Safety data
3	Control word and setpoints
4	Processing
B	Response telegram
5	Parameter response
6	Safety data
7	Status word and actual values

Processing of the process data in the frequency inverter is carried out with high priority, in order to ensure a rapid response to control commands or a change in status can be transmitted to the IO controller without delay.

Processing of PKW data is carried out with low priority and can take considerably longer.

The cyclic data traffic is carried out via parameter process data objects which are defined in PROFIBUS (PPO) which are defined in PROFIBUS, with which both process data (PZD) as well as parameters (PKW) are transferred from the IO controller/F-Host to the IO device/F-Device. NORD frequency inverters can process PPO types 1, 2, 3, 4 and 6.

Structure of PPO types

	PKW				PZD					
	PKE	IND	PWE	PWE	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
					STW	SW1	SW2	SW3	WAF 4	WAF 5
					ZSW	IW1	IW2	IW3	IW4	IW5
1st word	2nd word	3rd word	4th word	5th word	6th word	7th word	8th word			
PPO 1	x	x	x	x	x	x				
PPO 2	x	x	x	x	x	x	x	x		
					1st word	2nd word	3rd word	4th word	5th word	6th word
PPO 3					x	x				
PPO 4					x	x	x	x		
PPO 6					x	x	x	x	x	x

For detailed information see  Section 6.3.5 "Process data telegrams".

6.3 Transfer of process data

The control word (STW) and up to 3 Setpoints (SW) are transferred from the IO controller to the frequency inverter and the status word (ZSW) and up to 3 actual values (IW) are transferred from the frequency inverter to the IO controller as process data.

Addressing of the process data is performed with a slot/index combination. The slots and indices of NORD bus interfaces and frequency inverters are read by the IO controller from the device description file (see Section 5.2 "Integration into the bus master").






Figure 15: Example – PROFINET IP / PROFIsafe device model for decentralised devices

Designation	Description
DAP	Device Access Point, access point for communication with the Ethernet interface
SAFE	Extension for PROFIsafe field bus systems
TU	Bus interface
FI1...FI4	Frequency inverters 1...4

The length and structure of the process data are determined by the PPO types which the IO controller reads out from the device description file. The PPO types must be assigned to the slots for the bus participants during the configuration of the IO controller (PLC project). The PPO types are defined in the PROFIBUS profile.

6.3.1 Control word

The control word (STW) is the first word of a process data telegram which is sent from the bus master to the frequency inverter (order telegram) To switch the drive unit to standby, the frequency inverter must be set to "Ready for switch-on" status by transfer of the first control command "047Eh" ("10001111110b").

Bit	Designation	Value	Control command	Priority ¹
0	Ready for operation	0	Reverse with brake ramp, with voltage enabled at f=0 Hz (ready for operation)	3
		1	Set the frequency inverter to standby.	5
1	Disable voltage	0	Switch off the frequency inverter output voltage (the frequency inverter goes into the status "Switch-on block").	1
		1	Cancel "Disable voltage"	—
2	Emergency stop	0	Emergency stop with programmed emergency stop time. At f = 0 Hz voltage enable (the FI goes into "Switch-on block" status)	2
		1	Cancel operating condition "Emergency stop"	—
3	Enable operation	0	Block voltage: Switch off the frequency inverter output voltage (the frequency inverter goes into the status "Ready for switch-on").	6
		1	Enable output voltage Acceleration of the frequency inverter to the present setpoint.	4
4	Enable pulses	0	Acceleration encoder is set to zero; at f = 0 Hz no voltage enable (FI remains in "Operation enabled" status).	—
		1	Enable acceleration encoder	—
5	Enable ramp	0	Freeze the setpoint currently provided by the acceleration encoder (maintain frequency).	—
		1	Enable setpoint on acceleration encoder	—
6	Enable setpoint	0	Set the selected setpoint on the acceleration encoder to 0	—
		1	Activate the selected setpoint on the acceleration encoder.	—
7	Acknowledge the error (0→1)	0	With the switch from 0 to 1, inactive errors are acknowledged.	7
		1	Note: If a digital input has been programmed for the "ack.fault" function, this bit must not permanently be set to 1 via the bus, as otherwise, flank evaluation would be prevented.	
8	Start function 480.11	0		—
		1	Bus bit 8 of the control word is set  Parameter P480 in the frequency inverter manual.	
9	Start function 480.12	0		—
		1	Bus bit 9 of the control word is set  Parameter P480 in the frequency inverter manual.	
10 ²	Control data valid	0	The transmitted process data are invalid.	—
		1	The bus master transfers valid process data	
11 ³	Rotation right is on	0		—
		1	Switch on rotation right.	
12 ³	Rotation left is on	0		—
		1	Switch on rotation left (priority).	
13	Reserved			
14	Parameter set Bit 0 On	0		—
		1		
15	Parameter set Bit 1 On	0		—
		1		

Bit 15	Bit 14	it activates the parameter set
0	0	Parameter set 1
0	1	Parameter set 2
1	0	Parameter set 3
1	1	Parameter set 4



¹ If several control bits are set simultaneously, the priority stated in this column applies.

² The telegram is only interpreted as valid by the frequency inverter and the setpoints which are communicated via the field bus are only set if control bit 10 is set to 1.

³ If Bit 12 = 0, "rotational direction right ON" applies.
If Bit 12 = 1, "rotational direction left ON" applies, irrespective of Bit 11.

6.3.2 Status word

The status word (ZSW) is the first word of a process data telegram which is sent from the frequency inverter to the bus master (response telegram). With the status word, the status of the frequency inverter is reported to the bus master. As the response to the control word command "047Eh" the frequency inverter typically responds with "0B31h" ("101100110001b") and therefore indicates the status "Ready for switch-on".

Bit	Meaning	Value	Status message															
0	Ready to start	0																
		1	Initialisation completed, charging relay switched on, output voltage disabled															
1	Ready for operation	0	No switch-on command present, or there is a fault, of the command "Disable voltage" or "Emergency stop" is present, or the status is "Switch-on block".															
		1	There is a switch-on command and there is no fault. The inverter can be started with the command "Enable operation"															
2	Operation enabled	0																
		1	The output voltage is enabled; ramp of the frequency inverter up to the existing setpoint															
3	Fault	0																
		1	Drive unit defective and therefore "Not ready for operation". After acknowledgement, the frequency goes into status "Switch-on block".															
4	Voltage enabled	0	"Disable voltage" command present.															
		1																
5	Emergency stop	0	"Emergency stop" command present.															
		1																
6	Starting disabled	0																
		1	With the command "Standby" the frequency goes into status "Ready for switch-on".															
7	Warning active	0																
		1	Drive operation continues, no acknowledgement necessary															
8	Setpoint reached	0	Actual value does not correspond to the setpoint With use of POSICON: Setpoint position not reached.															
		1	Actual value matches the setpoint (setpoint reached) With use of POSICON: setpoint position has been reached															
9	Bus control active	0	Control on local device active															
		1	The master has been requested to take over control.															
10	Start function 481.9	0																
		1	Bus bit 10 of the status word is set  Parameter P481 in the frequency inverter manual.															
11	Rotation right is on	0																
		1	The frequency inverter output voltage has a right-hand rotation field.															
12	Rotation left is on	0																
		1	The frequency inverter output voltage has a left-hand rotation field.															
13	Start function 481.10	0																
		1	Bus bit 13 of the status word is set  Parameter P481 in the frequency inverter manual.															
14	Parameter set Bit 0 ON	0	<table border="1"> <thead> <tr> <th>Bit 15</th> <th>Bit 14</th> <th>parameter set, that is active</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Parameter set 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>Parameter set 2</td> </tr> <tr> <td>1</td> <td>0</td> <td>Parameter set 3</td> </tr> <tr> <td>1</td> <td>1</td> <td>Parameter set 4</td> </tr> </tbody> </table>	Bit 15	Bit 14	parameter set, that is active	0	0	Parameter set 1	0	1	Parameter set 2	1	0	Parameter set 3	1	1	Parameter set 4
		Bit 15		Bit 14	parameter set, that is active													
0	0	Parameter set 1																
0	1	Parameter set 2																
1	0	Parameter set 3																
1	1	Parameter set 4																
1																		
15	Parameter set Bit 1 On	0																
		1																

6.3.3 Frequency inverter status machine

The frequency inverter passes through a status machine. The changes between various states are triggered automatically or by control commands in the process data control word. The present status is returned in the process data status word.




Figure 16: Frequency inverter status machine

Item	Meaning
A...H	Frequency inverter statuses (Table "Frequency inverter statuses")
1...15	Status transitions (Table "Status transitions")

Frequency inverter statuses

Status		Description
A	Not on standby	Initial state after switching on the frequency inverter. As soon as the loading relay engages, the frequency inverter automatically changes to the status "Switch-on block".
B	Switch-on block	Second status after switching on the frequency inverter, which can only be exited with the control command "Shut-down". The charging relay is switched on.
C	Standby	In this status, initialisation of the frequency inverter is complete. The output voltage is blocked.
		<p>i Information</p> <p>During the initialisation process the response to a bus master telegram does not yet contain the response to the control command which has been issued. On the basis of the response from the bus participant, the control system must determine whether the control command has been executed.</p>
D	Activated	Frequency inverter ready for operation.
E	Operation enabled	The frequency inverter receives and processes setpoints.
F	Emergency stop active	Emergency stop function is being executed (the drive is stopped), the frequency inverter changes to the status "Switch-on block".
G	Error reaction active	If an error occurs, the frequency inverter changes to this status and all functions are blocked.
H	Fault	After processing of the response to the fault, the frequency inverter changes to this status, which can only be exited with the control command "Acknowledge fault".

Status transitions

Triggered status transition		Control command	Bit 7...0 of the control word ¹								
			7	6	5	4	3	2	1	0	
1	From "Not ready for switch-on" to "Switch on block"	—	—								
	Automatic activation of the charging relay										
2	From "Switch-on block" to "Ready for switch-on"	Shut down	X	X	X	X	X	1	1	0	
3	From "Ready for switch-on" to "Switched on"	Switch on	X	X	X	X	X	1	1	1	
4	From "Switched on" to "Operation enabled"	Enable operation	X	1	1	1	1	1	1	1	
	Output voltage is enabled										
5	From "Operation enabled" to "Switched on"	Disable operation	X	X	X	X	0	1	1	1	
	Output voltage is disabled										
6	From "Switched on" to "Ready for switch-on"	Shut down	X	X	X	X	X	1	1	0	
	Voltage enabled at "f = 0 Hz"										
7	From "Ready for switch-on" to "Switch-on block"	Disable voltage	X	X	X	X	X	X	0	X	
		Quick stop	X	X	X	X	X	0	1	X	
8	From "Operation enabled" to "Ready for switch-on"	Shut down	X	X	X	X	X	1	1	0	
9	From "Operation enabled" to "Switch on block"	Disable voltage	X	X	X	X	X	X	0	X	
10	From "Switched on" to "Switch on block"	Disable voltage	X	X	X	X	X	X	0	X	
		Quick stop	X	X	X	X	X	0	1	X	
11	From "Operation enabled" to "Emergency stop active"	Quick stop	X	X	X	X	X	0	1	X	
12	From "Emergency stop active" to "Switch on block"	Disable voltage	X	X	X	X	X	X	0	X	
13	Automatically, after the occurrence of a fault from any status	—	—								
14	Automatically after completion of the response to a fault	—	—								
15	End fault	Acknowledge error	0	X	X	X	X	X	X	X	X
			→								
			1	X	X	X	X	X	X	X	X

X = The bit status (0 or 1) is not important for achieving the status. Please also note the list of control bits, [Section 6.3.1 "Control word"](#).

¹ Complete list of control bits (Bit 0...15) [Section 6.3.1 "Control word"](#).


i Information

Control bit 10

Control bit 10 "Control data valid" must always be set to 1. Otherwise the process data will not be evaluated by the frequency inverter.

Decoded frequency inverter statuses

Status	Status bit ¹						
	6	5	4	3	2	1	0
Not ready for switch-on	0	X	X	0	0	0	0
Starting disabled	1	X	X	0	0	0	0
Ready to start	0	1	1	0	0	0	1
Activated	0	1	1	0	0	1	1
Operation enabled	0	1	1	0	1	1	1
Fault	0	X	X	1	0	0	0
Error active	0	X	X	1	1	1	1
Emergency stop active	0	0	1	0	1	1	1

¹ Complete list of status bits (Bit 0...15)  Section 6.3.2 "Status word".

6.3.4 Setpoints and actual values

Setpoints (from the bus master to the frequency inverter) and actual values (from the frequency inverter to the bus master) are specified via the following parameters of the frequency inverter:

Direction of transmission	Process value	Parameters
To bus interface	Setpoint 1	P546, Array [-01]
	Setpoint 2	P546, Array [-02]
	Setpoint 3	P546, Array [-03]
From bus interface	Actual value 1	P543, Array [-01]
	Actual value 2	P543, Array [-02]
	Actual value 3	P543, Array [-03]

Setpoints and actual values are transmitted by three different methods:

Percentage transmission

The process value is transmitted as an integer with a value range of -32768 to 32767 (8000 hex to 7FFF hex). The value "16384" (4000 hex) corresponds to 100%. The value "-16384" (C000 hex) corresponds to -100%.

For frequencies, the 100% value corresponds to parameter **P105 Maximum frequency** of the frequency inverter. For current, the 100% value corresponds to parameter **P112 Torque current limit** of the frequency inverter.

Frequencies and currents result from the following formulae:

$$Frequency = \frac{Value^* \times P105}{16384} \quad Current = \frac{Value^* \times P112}{16384}$$

* 16 Bit- setpoint or actual value which is transferred via the bus.

Binary transmission

Inputs and outputs as well as digital input bits and bus output bits are evaluated bit-wise.

Transmission of positions

In the frequency inverter, positions have a value range of -50000.00...50000.00 rotations. A rotation of the motor can be subdivided into a maximum of 1000 increments. The subdivision depends on the encoder which is used.

The 32 Bit value range is divided into a "Low" and a "High" word, so that two setpoints or actual values are required for the transmission.

Direction of transmission	Transmitted data			
	1st word	2nd word	3rd word	4th word
To bus interface	Control word	32 Bit setpoint		Setpoint 3
From bus interface	Status word	Actual value 1	32 Bit actual value	

Only the "Low" word for the position can also be transferred. This results in a limited value range from 32,767 to -32,768 rotations. This value range can be extended with the ratio factor (**Parameter P607 speed ratio** and **P608 Reduction**), however this reduces the resolution accordingly.

6.3.5 Process data telegrams

Getriebbau NORD GmbH & Co. KG uses the PPO types PPO3, PPO4 and PPO6 as process data telegrams for cyclic communication of process data.

PPO3

Direction of transmission	Transmitted data (4 Byte)	
	1st word	2nd word
To bus interface	Control word	Setpoint 1
From bus interface	Status word	Actual value 1

PPO4

Direction of transmission	Transmitted data (8 Byte)			
	1st word	2nd word	3rd word	4th word
To bus interface	Control word	Setpoint 1	Setpoint 2	Setpoint 3
From bus interface	Status word	Actual value 1	Actual value 2	Actual value 3

PPO6

Direction of transmission	Transmitted data (12 Byte)					
	1st word	2nd word	3rd word	4th word	5th word	6th word
To bus interface	Control word	Setpoint 1	Setpoint 2	Setpoint 3	-	-
From bus interface	Status word	Actual value 1	Actual value 2	Actual value 3	-	-

Getriebebau NORD GmbH & Co. KG uses the PPO types PPO1 and PPO2 for the cyclic exchange of process and parameter data.

PPO1

Direction of transmission	Transmitted data (12 Byte)					
	1st word	2nd word	3rd word	4th word	5th word	6th word
To bus interface	AK and PNU	IND	PWE HI	PWE LO	Control word	Setpoint 1
From bus interface	AK and PNU	IND	PWE HI	PWE LO	Status word	Actual value 1

AK Order label
 IND Parameter index
 PNU Parameter number
 PWE Parameter value

( Section 6.4 "Parameter data transmission")

PPO2

Direction of transmission	Transmitted data (16 Byte)							
	1st word	2nd word	3rd word	4th word	5th word	6th word	7th word	8th word
To bus interface	AK and PNU	IND	PWE HI	PWE LO	STW	Setpoint 1	Setpoint 2	Setpoint 3
From bus interface	AK and PNU	IND	PWE HI	PWE LO	ZSW	Actual value 1	Actual value 2	Actual value 3

AK Order label
 IND Parameter index
 PNU Parameter number
 PWE Parameter value

( Section 6.4 "Parameter data transmission")

6.4 Parameter data transmission

Transmission of parameter data is carried out acyclically. As with the process data, the parameter data are assigned via slots (☞ Section 6.3 "Transfer of process data"). The following are transferred

- Higher level parameter data for the bus interface (slot assignment 2)
- Parameter data for the frequency inverter FI1... (slot assignment 3...).

Using the PKW area (☞ Section 6.3 "Transfer of process data"), parameter processing can also be carried out in the cyclical data traffic. For this, the F-Host formulates an order and the inverter formulates the appropriate response to this. The PKW area is only used for the transfer of PPO types 1 and 2.

In principle, the PKW area consists of

- A **parameter identification**, in which the type of order (Write, Read etc.) and the relevant parameters are specified.
- An **Index (IND)**, with which the individual parameter sets or arrays are addressed,
- The **Parameter value (PWE)**, which contains the value which is to be read or written.

Field ¹		Data size	Explanation
PKE	Parameter label (Order label AK and parameter number PNU)	2 Byte	Parameter of the bus interface or the frequency inverter. The parameter number plus "1000". The order label is attached to the parameter number (upper nibble).
IND	Parameter index	2 Byte	Parameter sub-index
PWE	Parameter value	4 Byte	New setting value

¹ Description of the fields in the following sections.

A parameter order must be repeated until the inverter responds with the corresponding response telegram.

Information

Max. 100,000 permissible writing cycles

If parameter changes are made (order by the F-Host via the PKW channel), the maximum number of permissible writing cycles to the frequency inverter EEPROM (100,000 cycles) must not be exceeded. I.e. continuous cyclical writing must be prevented.

For certain applications it is sufficient if the values are only saved in the RAM of the frequency inverter. The corresponding setting can be made by selecting the appropriate AK or via the parameter **P560 Save in EEPROM**.

6.4.1 Structure of acyclic parameter data exchange (Records)




Figure 17: Sequence of acyclic PROFINET IO parameter data exchange


Item	Meaning	Comments
A	Parameter order	
W	Parameter response	
1	Write Request (with data, Slot 3...6)	By means of a "Write Request" the data record is transferred to the IO device as a parameter order.
2	Write Response (without data, Slot 3...6)	With "Write Response" the IO controller receives confirmation of the receipt of the message.
3	Read Request (without data, Slot 3...6)	With a "Read Request" the IO controller orders a response from an IO device.
4	Read Response (-) (without data, Slot 3...6)	The IO device responds with a "Read Response (-)", if processing is not yet complete.
5	Read Request (without data, Slot 3...6)	With a "Read Request" the IO controller orders a response from an IO device.
6	Read Response (+) (with data, Slot 3...6)	After processing the parameter order, the IO device responds with "Read Response (+)". The parameter order is complete.

During the communication of parameter orders, the positive response from the IO device to the IO controller can be delayed by one or more communication cycles. The IO controller must therefore repeat the order until the corresponding response is received from the IO device.

6.4.2 Data records for acyclic parameter orders

Parameter orders are transferred as data records. The data records are generally transferred to the bus interface (Slot 2). The number of the data record determines the recipient of the parameter order:

Data record 100	Order to the bus interface (Parameter P150...P199)
Data record 101	Order to frequency inverter 1 (Parameter P000...P149 and P200...P999)
Data record 102	Order to frequency inverter 2 (Parameter P000...P149 and P200...P999)
...	
Data record 108	Order to frequency inverter 8 (Parameter P000...P149 and P200...P999)

The structure of these data records is described in Section  6.4 "Parameter data transmission" ("PKW area").



Information

Parameter numbers

Getriebebau NORD GmbH & Co. KG parameter numbers P000...P999 must be converted into the numerical range 1000...1999, i.e. "1000" must be added to the parameter numbers for parameterisation.


6.4.3 Data record format

6.4.3.1 Parameter label PKE

The order or response and the associated parameters are encrypted in the parameter label PKE.

PKE																IND	PWE1	PWE2
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
AK				SPM	PNU													

The parameter label (PKE) is always a 16 bit value.

- PNU** Bits 0...10 contain the number of the required parameters or the number of the current parameter in the response telegram of the frequency inverter.
Parameter numbers  Manual for the relevant frequency inverter.
- SPM** Bit 11 is the toggle-bit for spontaneous messages. This function is **not** supported.
- AK** Bits 12...15 contain the order or response label.

Information

Parameter numbers

Getriebbau NORD GmbH & Co. KG parameter numbers P000...P999 must be converted into the numerical range 1000...1999, i.e. "1000" must be added to the parameter numbers for parameterisation.

Order label and response label AK

A total of 15 parameter orders can be transferred from the <v>T - Busmaster</v>.

The right-hand column of the following table lists the corresponding label of a positive response The label of a positive response depends on the order label.

Meaning of order labels

Order label	Function	Response label (positive)
0	No order	0
1	Order parameter value	1 or 2
2	Change parameter value (word)	1
3	Change parameter value (double word)	2
4	Reserved	—
5	Reserved	—
6	Order parameter value (array)	4 or 5
7	Change parameter value (array, word)	4
8	Change parameter value (array, double word)	5
9	Order the number of array elements	6
10	Reserved	—
11	Change parameter value (array, double word) without writing to the EEPROM	5
12	Change parameter value (array, word) without writing to the EEPROM	4
13	Change parameter value (double word) without writing to the EEPROM	2
14	Change parameter value (word) without writing to the EEPROM	1

Parameter orders with order labels 0...10 can only be transferred to frequency inverters.

Parameters orders with order labels 11...14 can be transferred to both frequency inverters as well as to the bus interface.

Meaning of response labels

Response label	Meaning
0	No response
1	Transfer parameter value (word)
2	Transfer parameter value (double word)
4	Transfer parameter value (array, word)
5	Transfer parameter value (array, double word)
6	Transfer the number of array elements
7	Order cannot be executed (with error number in PWE2)

The label for a negative response is always the value "7" (order cannot be executed) for all order labels. In case of a negative response, an error message is also listed in the response from the frequency inverter in PWE2.

Meaning of error messages in parameter value PWE2

Error message	Meaning
0	Invalid parameter number
1	Parameter value cannot be changed
2	Lower or upper value limit exceeded
3	Incorrect sub-index
4	No array
5	Invalid data type
6	Only resettable (only 0 may be written)
7	Description element cannot be changed
9	Description data not present
201	Invalid order element in the last order received
202	Internal response label cannot be depicted

 Information**Order and response labels**

Both the order label and the response label are abbreviated as "AK" in the data telegram. Because of this, especially the response or order labels "AK1", "AK2" and "AK4" to "AK7" must be carefully interpreted.

6.4.3.2 Parameter index IND

The structure and function of the parameter index depends on the type of parameter to be transmitted.

PKE	IND															PWE1	PWE2
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1		
							P1...P4		No information (all "0")								
	Arrays 1...64						P1...P4										
	Sub-index																

For **values which depend on the parameter set**, the parameter set can be selected via Bit 8 and Bit 9 of the index (0 = Parameter set 1, 1 = Parameter set 2 etc.).

For **array parameters** the sub-index can be addressed via Bit 10 to Bit 15 (0 = Array element 1, 1 = Array element 2 etc.).

For **parameters which do not depend on the parameter set**, Bit 8 to Bit 15 are used for the sub-index. In order for the sub-index to be effective, the corresponding order label (numbers 6, 7, 8 and 11 and 12) must be used.

Examples for address formation for array parameters which depend on parameter sets

Array element						Parameter set		No information							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	1	0	1	0	1	No information (all "0")							
5 (0001 01b)						2 (01b)									

Array element						Parameter set		No information							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	1	0	1	0	1	1	1	No information (all "0")							
21 (0101 01b)						4 (11b)									

Structure of parameter and sub-index values  Manual for the relevant frequency inverter.

6.4.3.3 Parameter value PWE

According to the parameter, parameter values are transmitted as a word (16 Bit) or as a double word (32 Bit). For negative values, the High bytes must be filled up with "FFh"

The parameter value is transferred as an integer value.

For parameters with resolutions "0.1" or "0.01" the parameter value must be multiplied by the inverse of the resolution.

Example

A run-up time of 99.99 seconds is to be set.

$$99.99_s = \frac{99.99 \times 1}{0.01} = 99.99 \times 100 = 9999$$

The value "9999" (270Fh) must be transferred.

6.4.4 Examples of data record transfer

6.4.4.1 Reading of parameter P717 current speed

Data record 100 is used.

Example telegram

Field	Data size	Byte	Date	Explanation
Order label AK	1 Byte (upper Nibble)	2	1h	Order parameter value (read)
and Parameter value PWE	1 Byte (lower Nibble)			6B5h
			16B5h	
Parameter index	2 Byte	3	00h	Parameter sub-index
		4	00h	
Parameter value	4 Byte	5	00h	Setting value not set with read order
		6	00h	
		7	00h	
		8	00h	

Example code (SIMATIC STEP 7 V5.5)	Explanation
CALL „WRREC“, DB53 REQ :=#bStart ID :=DW#16#7FC INDEX :=100 LEN :=8 DONE :=#bEnd BUSY :=#bBusy ERROR :=#bError STATUS :=wStatus RECORD :=P#DB10.DBX0.0 BYTE 8	→ Write Request → Diagnosis address → Data record 100 → Length: 8 Byte
CALL “RDREC”, DB52 REQ :=#bStart ID :=DW#16#7FC INDEX :=100 MLEN :=8 VALID :=... BUSY :=... ERROR :=... STATUS :=... LEN :=... RECORD :=P#DB10.DBX12.0 BYTE 8	→ Read Response → Diagnosis address → Data record 100
Read value: P717 = 1020 (03FCh)	

6.4.4.2 Writing of parameter P102 acceleration time, Index 1

Data record 101 is used.

Example telegram

Field	Data size	Byte	Date	Explanation
Order label AK	1 Byte (upper Nibble)	2	2h	Order parameter value (read)
and Parameter value PWE	1 Byte (lower Nibble)			44Eh
			244Eh	
Parameter index	2 Byte	3	01h	Parameter sub-index
		4	00h	
Parameter value	4 Byte	5	00h	The time "2.5 s" (250 = FAh) is to be set.
		6	00h	
		7	00h	
		8	FAh	

Example code (SIMATIC STEP 7 V5.5)	Explanation
CALL „WRREC“, DB53 REQ :=#bStart ID :=DW#16#7FC INDEX :=101 LEN :=8 DONE :=#bEnd BUSY :=#bBusy ERROR :=#bError STATUS :=wStatus RECORD :=P#DB10.DBX0.0 BYTE 8	→ Write Request → Diagnosis address → Data record 101 → Length: 8 Byte → Data: 24h, 4Eh, 01h, 00h, 00h, 00h, 00h, FAh
CALL “RDREC”, DB52 REQ :=#bStart ID :=DW#16#7FC INDEX :=101 MLEN :=8 VALID :=... BUSY :=... ERROR :=... STATUS :=... LEN :=... RECORD :=P#DB10.DBX12.0 BYTE 8	→ Read Response → Reference → Data record 101 → Response: 14h, 4Eh, 01h, 00h, 00h, 00h, 00h, 00h

6.4.4.3 Telegram structure for parameterisation via PPO1 or PPO2

The parameter **P102 acceleration time** is to be set to the value "10 s" in parameter set 3 (only the PKW channel is considered). As the acceleration time has an internal resolution of "0.01 s" in the FI, the parameter value "1000" ("3E8h") must be transferred.

Procedure

1. Specify the order label (CAK 7 = "Change parameter value (Array, Word)").
2. Select parameter (P102 = P66h).
3. Select parameter set 3 (IND = 02).
4. Set parameter value (1000 = 3E8h).
5. Check response telegram (positive for array word 4).

Order telegram from IO controller

Word	1		2		3		4	
Byte	0	1	2	3	4	5	6	7
Designation	PKE	PKE	IND	IND	PWE	PWE	PWE	PWE
Value	70h	66h	02h	00h	00h	00h	03h	E8h

Response telegram from frequency inverter (after complete processing of the order)

Word	1		2		3		4	
Byte	3	4	5	6	7	8	9	10
Designation	PKE	PKE	IND	IND	PWE	PWE	PWE	PWE
Value	40h	66h	02h	00h	00h	00h	03h	E8h

6.5 F-Data transmission

Transmission of the F-Data (safety data) is performed within a PROFINET IO telegram.




Figure 18: F-Data exchange

Order telegram A

Byte	Bit	Meaning
0	0	Switch OSSD 1
	1	Reserved
	2	
	3	Enable SOS
	4	Enable SLS
	5	Reserved
	6	
	7	
1	0	Reserved
	1	Select SLS speed
	2	
	3	Reserved
	4	Enable SDI-P
	5	Enable SDI-N
	6	Reserved
	7	

Byte	Bit	Meaning
2	0	Reserved
	1	
	2	
	3	
	4	
	5	
	6	
	7	
3	0	Switch OSSD2
	1	Switch OSSD3
	2	Reserved
	3	
	4	
	5	
	6	Enable SSR
	7	Acknowledge channel passivation

Byte	Bit	Meaning
4	0	Control Byte
	1	
	2	
	3	
	4	
	5	
	6	
	7	
5	0	Checksum check CRC2
	1	
	2	
	3	
	4	
	5	
	6	
	7	

Byte	Bit	Meaning
6	0	Checksum check CRC2
	1	
	2	
	3	
	4	
	5	
	6	
	7	
7	0	Checksum check CRC2
	1	
	2	
	3	
	4	
	5	
	6	
	7	

Response telegram B

Byte	Bit	Meaning
0	0	Status OSSD1
	1	Reserved
	2	
	3	SOS status
	4	SLS status
	5	Reserved
	6	
	7	
1	0	Reserved
	1	SLS speed coding
	2	
	3	Reserved
	4	SDI-P status
	5	SDI-N status
	6	
	7	SSM status
2	0	Reserved
	1	
	2	
	3	
	4	
	5	
	6	
	7	
3	0	OSSD2 status
	1	OSSD2 status
	2	Clock output 1 status
	3	Clock output 2 status
	4	Digital input 1 status
	5	Digital input 2 status
	6	SSR status
	7	Reserved

Byte	Bit	Meaning
4	0	Status Byte
	1	
	2	
	3	
	4	
	5	
	6	
	7	
5	0	Checksum check CRC2
	1	
	2	
	3	
	4	
	5	
	6	
	7	
6	0	Checksum check CRC2
	1	
	2	
	3	
	4	
	5	
	6	
	7	
7	0	Checksum check CRC2
	1	
	2	
	3	
	4	
	5	
	6	
	7	

6.5.1 F-Parameters

When the PROFINET IO field bus system is started, the safety-relevant parameters (F-Parameters) from the F-Host are transmitted to the PROFIsafe bus interface and checked for plausibility. The exchange of data only starts after a successful plausibility check.

The following table lists the F-Parameters which must be transmitted from the F-Host to the bus interface.

Parameters	Byte	Type	Meaning	Explanation
F_Check_iPar	0	1 Bit	0 = No Testing	The parameter cannot be changed and is set to "NoCheck".
F_SIL		2 Bit	00 = SIL 1	This parameter states the safety integrity level which the user expects from the F-Device. The PROFIsafe bus interface supports the safety classes "No SIL", and SIL 1 to SIL 3 (default value = SIL 3).
			01 = SIL 2	
			10 = SIL 3 (default)	
F_CRC_Length		2 Bit	00 = 3-Byte CRC	The PROFIsafe bus interface supports a CRC length of 3 byte. This value is pre-set and cannot be changed.
F_Block_ID	1	3 Bit	001 = Default = 1	This parameter is pre-set with the value "1" (F_iPar_CRC in the data block) and cannot be changed.
F_Par_Version		2 Bit	01 = V2 Mode	This parameter identifies the implemented PROFIsafe version "V2 Mode". This value is pre-set and cannot be changed.
F_Source_Add	2	Unsigned 16	Source address, Default = 1, Range: 1...65534	This parameter identifies a unique source address within the PROFIsafe network.
	3			
F_Dest_Add	4	Unsigned 16	Destination address, Default = 1, Range 1...65534	This parameter identifies a unique destination address within the PROFIsafe network.
	5			
F_WD_Time	6	Unsigned 16	Watchdog time, Default = 100, Range: 1...10000 ms	This determines the monitoring time (in ms) in the PROFIsafe system (the pre-set time is "100 ms"). If no valid safety telegram is received from the F-Host within this time, the bus interface switches to the safe condition. The watchdog time must be selected so that telegram run times are tolerated by the communication and the response function is executed quickly enough in case of a fault.
	7			
F_iPar_CRC	8	Unsigned 32	CRC of the i-Parameters, Range: 0...4295967295	This parameter states the checksum (CRC3), from which all i-Parameters of the bus interface are calculated and ensures the safe transmission of the parameters.
	9			
	10			
	11			
F_Par_CRC	12	Unsigned 16	CRC of the F-Parameters, Range: 0...65535	This parameter states the checksum (CRC1), from which all F-Parameters of the bus interface are calculated and ensures the safe transmission of the F-Parameters.
	13			

6.5.2 Structure of F-Input and F-Output data

F-input data

Information

Important: The F-Input data switches the safe outputs and the safety functions. If these are not enabled via i-Parameter, an error is triggered.

Date	"High" function	"Low" function
F-Data In 0.0	Switch on OSSD 1	Switch off OSSD 1
F-Data In 0.1	—	—
F-Data In 0.2	—	—
F-Data In 0.3	Switch on SOS monitoring after activation time	Switch off SOS monitoring immediately
F-Data In 0.4	Switch on SLS monitoring after activation time	Switch off SLS monitoring immediately
F-Data In 0.5	—	—
F-Data In 0.6	—	—
F-Data In 0.7	—	—
F-Data In 1.0	—	—
F-Data In 1.1	Selection of SLS speed Bit 0 – monitoring enabled after activation time	
F-Data In 1.2	Selection of SLS speed Bit 1 – monitoring enabled after activation time	
F-Data In 1.3	—	—
F-Data In 1.4	Switch on SDI-P monitoring after activation time	Switch off SDI-P monitoring immediately
F-Data In 1.5	Switch on SDI-N monitoring after activation time	Switch off SDI-N monitoring immediately
F-Data In 1.6	—	—
F-Data In 1.7	—	—
F-Data In 2.0	—	—
F-Data In 2.1	—	—
F-Data In 2.2	—	—
F-Data In 2.3	—	—
F-Data In 2.4	—	—
F-Data In 2.5	—	—
F-Data In 2.6	—	—
F-Data In 2.7	—	—
F-Data In 3.0	Switch on OSSD 2	Switch off OSSD 2
F-Data In 3.1	Switch on OSSD 3	Switch off OSSD 3
F-Data In 3.2	—	—
F-Data In 3.3	—	—
F-Data In 3.4	—	—
F-Data In 3.5	—	—
F-Data In 3.6	Switch on SSR after activation time	—
F-Data In 3.7	Acknowledge channel passivation → Error is cancelled	—

F-Output data

Date	"High" function	"Low" function
F-Data Out 0.0	OSSD 1 switched off	OSSD 1 switched on
F-Data Out 0.1	—	—
F-Data Out 0.2		
F-Data Out 0.3	SOS enabled (combination of i-Parameters and F-Data) and deviation of position within the limit value	SOS not enabled or deviation of position outside of the limit value
F-Data Out 0.4	SLS enabled (combination of i-Parameters and F-Data) and speed within the set range	SLS not enabled or speed outside of the set range
F-Data Out 0.5	—	—
F-Data Out 0.6		
F-Data Out 0.7		
F-Data Out 1.0		
F-Data Out 1.1	SLS speed Bit 0	
F-Data Out 1.2	SLS speed Bit 1	
F-Data Out 1.3	—	—
F-Data Out 1.4	SDI-P enabled (combination of i-Parameters and F-Data) and direction of rotation positive or speed = "0"	SDI-P not enabled or direction of rotation negative
F-Data Out 1.5	SDI-N enabled (combination of i-Parameters and F-Data) and direction of rotation negative or speed = "0"	SDI-N not enabled or direction of rotation positive
F-Data Out 1.6	—	—
F-Data Out 1.7	SSM speed within the set range	SSM speed outside of the set range
F-Data Out 2.0	—	—
F-Data Out 2.1		
F-Data Out 2.2		
F-Data Out 2.3		
F-Data Out 2.4		
F-Data Out 2.5		
F-Data Out 2.6		
F-Data Out 2.7		
F-Data Out 3.0	OSSD 2 switched off	OSSD 2 switched on
F-Data Out 3.1	OSSD 3 switched off	OSSD 3 switched on
F-Data Out 3.2	Clock 1 switched off	Clock 1 switched on
F-Data Out 3.3	Clock 2 switched off	Clock 2 switched on
F-Data Out 3.4	Input 1 enabled	Input 1 not enabled
F-Data Out 3.5	Input 2 enabled	Input 2 not enabled
F-Data Out 3.6	SSR enabled (combination of i-Parameters and F-Data) and speed within the set range	SSR not enabled or speed outside of the set range
F-Data Out 3.7	—	—

6.6 Example of setpoint specification

The following example shows the specification of a setpoint for switching a frequency inverter on and off. The frequency inverter is operated with a setpoint (setpoint frequency) and responds with an actual value (actual frequency). The maximum frequency is set to 50 Hz.

Parameter settings on the frequency inverter:

Parameter No.	Parameter name	Setting value
P105	Maximum frequency	50 Hz
P543	Actual bus value 1	1 (= Actual frequency)
P546	Function bus setpoint 1	1 (= Setpoint frequency)

Example



Order to FI		Response from the FI		Remarks
Control word	Setpoint 1	Status word	Actual value 1	
—	—	0000h	0000h	
—	—	xx40h	0000h	The mains voltage is switched on at the frequency inverter
047Eh	0000h	xx31h	0000h	The frequency inverter switches to "Ready for switch-on" status
047Fh	2000h	xx37h	2000h	The frequency inverter is set to "Operation enabled" status and controlled with a 50 % setpoint.
The frequency inverter is enabled, the motor is supplied with current and rotates with a frequency of 25 Hz.				
0047Eh	2000h	xx31h	0000h	The frequency inverter switches to "Ready for switch-on" status The motor brakes to a standstill according to the parameterised ramp and is disconnected from the power supply.
The frequency inverter is blocked again and the motor is without current.				
047Fh	1000h	xx37h	1000h	The frequency inverter is set to "Operation enabled" status and controlled with a 25% setpoint.
The frequency inverter is enabled, the motor is supplied with current and rotates with a frequency of 12.5 Hz.				

7 Parameters

The bus interface and frequency inverter parameters are communicated as words (16 Bit/Word). Exceptions to this are position values (POSICON), which are communicated as double words (32 Bit).

For field bus operation, several parameters must be set on the bus interface and the frequency inverter.

The parameters can be set with

- An external control or ParameterBox ( Manual [BU 0040](#)),
- NORD CON software ( Manual [BU 0000](#)) or
- The operator's PLC project.

7.1 Parameter setting on the bus interface

The parameters of the bus interface are divided into NORD-specific standard parameters and NORD-specific and field-bus specific information parameters:

Parameter No.	Description
P15x	NORD standard parameter (can be set and saved)
P16x	PROFINET IO standard parameter (can be set and saved)
P800...P839	PROFIsafe standard parameter (can be set and saved)
P17x	NORD information parameter (display)
P18x	PROFINET IO information parameter (display)
P840...P850	PROFIsafe information parameter (display)

- The NORD standard parameters **P151**, **P153** and **P154** must be set on the bus interface SK CU4-PNS.
- Depending on the application and the configuration the PROFINET IO standard parameters **P160** to **P162** and **P164** and the PROFIsafe standard parameters **P800** to **P824** must be set on the bus interface SK TU4-PNS.

A detailed description of the bus interface parameters can be found in the following sections.

7.1.1 NORD standard parameters

The basic settings of the bus interface can be made via NORD standard parameters.

P150	Set relay			
Setting range	0...4			
Factory setting	{ 0 }			
Bus interface	SK TU4-PNS			
Description	The setting of this parameter determines the switching state of each digital output.			
Setting values	Value	Meaning	Comments	
	0	Via bus	All digital outputs are controlled via the PROFINET. The functions are defined in the frequency inverter (P480).	
	1	Outputs Off	All digital outputs are set to "Low" (0 V)	
	2	Output 1 On (DO1)	Digital output DO1 is set to "High" (active), digital output DO2 is set to "Low" (0 V).	
	3	Output 2 On (DO2)	Digital output DO2 is set to "High" (active), digital output DO1 is set to "Low" (0 V).	
	4	Outputs 1 and 2 ON	All digital outputs are set to "High" (active)	

P151	Timeout for external bus																																			
Setting range	0...32767 ms																																			
Factory setting	{ 0 }																																			
Bus interface	SK CU4-PNS, SK TU4-PNS																																			
Description	Monitoring function of the bus interface After receipt of a valid telegram, the next telegram must arrive within the set time. Otherwise the bus interface or the connected frequency inverter reports an error (E010/10.3 "Time Out") and switches off. See also parameter P513 Telegram timeout time for the frequency inverter.																																			
Setting values	-1 = Monitoring Off																																			
	0 = Control word monitoring Off, bus-communication monitoring active																																			
Note	The following table shows an overview of the responses of the device to typical user errors in combination with certain monitoring parameter settings:																																			
	<table border="1"> <thead> <tr> <th rowspan="2">Action</th> <th>Setting value</th> <th>Error of the bus interface</th> </tr> <tr> <th>P151</th> <th></th> </tr> </thead> <tbody> <tr> <td>Invalid control word set (e.g. PLC to Stop)</td> <td>-1</td> <td>Frequency inverter continues operation</td> </tr> <tr> <td>Connection to F-Host lost</td> <td>-1</td> <td>Frequency inverter continues operation</td> </tr> <tr> <td>Ethernet cable interrupted</td> <td>-1</td> <td>Frequency inverter continues operation</td> </tr> <tr> <td>Invalid control word set (e.g. PLC to Stop)</td> <td>0 sec</td> <td>Frequency inverter continues operation</td> </tr> <tr> <td>Connection to F-Host lost</td> <td>0 sec</td> <td>Error E10.2*</td> </tr> <tr> <td>Ethernet cable interrupted</td> <td>0 sec</td> <td>Error E10.5*</td> </tr> <tr> <td>Invalid control word set (e.g. PLC to Stop)</td> <td>1 sec</td> <td>Error E10.3*</td> </tr> <tr> <td>Connection to F-Host lost</td> <td>1 sec</td> <td>Error E10.2*</td> </tr> <tr> <td>Ethernet cable interrupted</td> <td>1 sec</td> <td>Error E10.5*</td> </tr> </tbody> </table>				Action	Setting value	Error of the bus interface	P151		Invalid control word set (e.g. PLC to Stop)	-1	Frequency inverter continues operation	Connection to F-Host lost	-1	Frequency inverter continues operation	Ethernet cable interrupted	-1	Frequency inverter continues operation	Invalid control word set (e.g. PLC to Stop)	0 sec	Frequency inverter continues operation	Connection to F-Host lost	0 sec	Error E10.2*	Ethernet cable interrupted	0 sec	Error E10.5*	Invalid control word set (e.g. PLC to Stop)	1 sec	Error E10.3*	Connection to F-Host lost	1 sec	Error E10.2*	Ethernet cable interrupted	1 sec	Error E10.5*
Action	Setting value	Error of the bus interface																																		
	P151																																			
Invalid control word set (e.g. PLC to Stop)	-1	Frequency inverter continues operation																																		
Connection to F-Host lost	-1	Frequency inverter continues operation																																		
Ethernet cable interrupted	-1	Frequency inverter continues operation																																		
Invalid control word set (e.g. PLC to Stop)	0 sec	Frequency inverter continues operation																																		
Connection to F-Host lost	0 sec	Error E10.2*																																		
Ethernet cable interrupted	0 sec	Error E10.5*																																		
Invalid control word set (e.g. PLC to Stop)	1 sec	Error E10.3*																																		
Connection to F-Host lost	1 sec	Error E10.2*																																		
Ethernet cable interrupted	1 sec	Error E10.5*																																		
	* Error E10.2 = Watchdog bus-communication Error E10.3 = Bus Timeout (P151/P513) Error E10.8 = No Ethernet connection																																			

P152	Factory setting																		
Setting range	0...3																		
Factory setting	{ 0 }																		
Bus interface	SK CU4-PNS, SK TU4-PNS																		
Description	Reset the present parameter settings of the bus interface to the factory setting.																		
Setting values	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> <th>Remarks</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No change</td> <td>Current parameter settings will not be changed</td> </tr> <tr> <td>1</td> <td>Load factory setting</td> <td>All bus interface parameters will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.</td> </tr> <tr> <td>2</td> <td>Basic parameters</td> <td>All basic parameters of the bus interface will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.</td> </tr> <tr> <td>3</td> <td>i-Parameters</td> <td>The individual safety parameters (P800 ... P830) of the bus interface will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.</td> </tr> </tbody> </table>				Value	Meaning	Remarks	0	No change	Current parameter settings will not be changed	1	Load factory setting	All bus interface parameters will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.	2	Basic parameters	All basic parameters of the bus interface will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.	3	i-Parameters	The individual safety parameters (P800 ... P830) of the bus interface will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.
Value	Meaning	Remarks																	
0	No change	Current parameter settings will not be changed																	
1	Load factory setting	All bus interface parameters will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.																	
2	Basic parameters	All basic parameters of the bus interface will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.																	
3	i-Parameters	The individual safety parameters (P800 ... P830) of the bus interface will be reset to the factory setting. The setting of parameter P152 then automatically changes back to { 0 }.																	
P153	Min. system bus cycle																		
Setting range	0...250 ms																		
Arrays	[-01] = TxSDO Inhibit Time [-02] = TxPDO Inhibit Time																		
Factory setting	{ [-01] = 10 } { [-02] = 5 }																		
Bus interface	SK CU4-PNS, SK TU4-PNS																		
Description	Set the pause time for the system bus in order to reduce the bus load.																		

P154	TB-IO access		
Setting range	0...5		
Arrays	[-01] = Access to inputs [-02] = Access to outputs		
Factory setting	{ [-01] = 0 } { [-02] = 0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Assign reading and writing rights of each connected frequency inverter to 2 inputs and 2 outputs of the bus interface. This is carried out via the following frequency inverter parameters:		
	Input 1	Evaluation via P480 Funct. BusIO In Bits , Array [-11]	
	Input 2	Evaluation via P480 Funct. BusIO In Bits , Array [-12]	
	Output 1	Evaluation via P481 Funct. BusIO Out Bits , Array [-09]	
	Output 2	Evaluation via P481 Funct. BusIO Out Bits , Array [-10]	
Setting values	Value	Meaning	Comments
	0	No access	No influence by the frequency inverter.
	1	Broadcast (inputs)	All connected frequency inverters read the inputs (Array [-02] = No function).
	2	FI 1	Frequency inverter 1 reads and writes to the inputs and outputs.
	3	FI 2	Frequency inverter 2 reads and writes to the inputs and outputs.
	4	FI 3	Frequency inverter 3 reads and writes to the inputs and outputs.
	5	FI 4	Frequency inverter 4 reads and writes to the inputs and outputs.

7.1.2 PROFINET IO standard parameters

Field-bus specific settings of the bus interface can be made via the PROFINET IO standard parameters.

P160	IP address			
Setting range	0...255			
Arrays	[-01] = IP-High (NET-ID)		[-03] = IP (NET-ID)	
	[-02] = IP (NET-ID)		[-04] = IP Lo (Host)	
Factory setting	{ [-01] = 192 }	{ [-02] = 168 }	{ [-03] = 20 }	{ [-04] = 200 }
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Set the IP address for the bus interface, consisting of 4 bytes.			
Note	<p>If the IP address of the bus interface has been configured in the PLC project, this is automatically assigned to the bus interface when the IO controller is started up. This parameter is then set to "0". In this case, the currently set IP address can be obtained via parameter P185.</p> <p>If the IP address which is entered does not conform with the IP sub-net mask which is entered in parameter P161 the IP sub-net mask is corrected automatically.</p> <p>If the IP address is changed (e.g. with NORD CON software), this is only saved after a value is entered in Array [-04].</p>			
P161	IP sub-net mask			
Setting range	0...255			
Arrays	[-01] = IP Sub 1	[-02] = IP Sub 2	[-03] = IP Sub 3	[-04] = IP Sub 4
Factory setting	{ [-01] = 255 }	{ [-02] = 255 }	{ [-03] = 255 }	{ [-04] = 0 }
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Set the IP sub-net mask for the bus interface, consisting of 4 bytes.			
Note	<p>If the IP sub-net mask has been configured in the PLC project, this is automatically assigned to the bus interface when the IO controller is started up. This parameter is then set to "0". In this case, the currently set IP sub-net mask can be obtained via parameter P186.</p> <p>If the IP sub-net mask is changed (e.g. with NORD CON software), this is only saved after a value is entered in Array [-04].</p> <p>If the IP sub-net mask does not conform with the IP address which is entered in P160 the entry is not saved.</p>			


P162	Device name		
Setting range	45...122 (ASCII)		
Factory setting	{ 0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Enter the device name for the bus interface in the PROFINET IO bus system.		
Note	<p>In order for the bus interface to be detected when the IO controller is started up, the device name which is entered here must conform with the device name which is assigned in the PLC project.</p> <p>Observe the following conventions when entering the device name:</p> <ul style="list-style-type: none"> • The device name may have a maximum of 127 characters. Lower case letters a...z, numbers 0...9, hyphens /-" and fullstops "." are permissible. • A character string between two hyphens or two full stops may only have a maximum length of 63 characters. • The device name must not contain any special characters (umlauts, brackets, slashes and underscores etc.) or spaces. • The device name must not begin or end with a hyphen. • The device name must not begin or end with a number. • The device name must not have the format "n.n.n.n" or start with the character sequence "port-<i>nnn</i>" (<i>n</i> = 0...9). 		
P163	Testing the alarm		
Setting range	0...255		
Arrays	[-01] = Slot 0 (DAP – reserved) [-02] = Slot 1 (SAFE device – reserved) [-03] = Slot 2 (bus interface) [-04]...[-07] = Slot 3...6 (FI1...4) [-08]...[-11] = Slot 7...10 (FI5...8) ¹		
Factory setting	{ [-01]...[-11] = 0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Enter the error number to trigger a diagnostic alarm on one of the slots (e.g. during commissioning).		
Note	When the entry is saved, an alarm is triggered on the relevant slot. Set the value back to "0" to reset the alarm.		
Example	Trigger alarm with error 5.0 on Slot 3:		
	P163 Array [-04]	→ ChannelErrorType	= 0x100+50=0x132

1) Not available.

P164	IP Gateway			
Setting range	0...255			
Arrays	[-01] = IP High (NET-ID)		[-03] = IP (NET-ID)	
	[-02] = IP (NET-ID)		[-04] = IP Lo (Host)	
Factory setting	{ [-01] = 0 }	{ [-02] = 0 }	{ [-03] = 0 }	{ [-04] = 0 }
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Set the IP address for the gateway function, consisting of 4 bytes.			
Note	<p>If the IP address for the gateway function has been configured in the PLC project, this is automatically assigned to the bus interface when the IO controller is started up. This parameter is then set to "0". In this case, the currently set IP address can be obtained via parameter P187.</p> <p>If the IP address is changed (e.g. with NORD CON software), this is only saved after a value is entered in Array [-04].</p>			

7.1.3 NORD information parameters

NORD information parameters are used to display current and archived error messages, as well as current operating states.

P170	Actual error		
Display range	0...9999		
Arrays	[-01] = Actual error in bus interface [-02] = Last error in bus interface		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the actual error present. For a list of possible error messages please refer to  Section 8 "Error monitoring and error messages".		
Note	The error message is reset when the supply voltage is switched off.		
P171	Software version		
Display range	0.0...9999.9		
Arrays	[-01] = Software version [-02] = Software revision [-03] = Special version		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the software version and revision number of the bus interface. Array [-03] shows possible special versions (0 = standard version).		
P172	Configuration level		
Display range	0...		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the bus interface identifier.		
Display values	Value	Meaning	
	0 - 4	-	Not available.
	5	TU4safe	Bus interfaceSK TU4-PNS

P173	Module status				
Display range	0...FFFFh				
Arrays*	[-01]...[-02]				
Bus interface	SK CU4-PNS, SK TU4-PNS				
Description	Displays the operating status of the bus interface.				
Display values	Bit	Meaning Array [-01]			Meaning Array [-02]
	0	Initialisation			FI 1 status
	1	Application Relation established			
	2	Ethernet connection			FI 2 status
	3	Timeout (P151/P513)			
	4	Status error code			FI3 status
	5	Status error code			
	6	Status error code			FI4 status
	7	System bus Error / Warning			
	8	FI1 status			FI5 status ¹⁾
	9				
	10	FI 2 status			FI6 status ¹⁾
	11				
	12	FI 3 status			FI7 status ¹⁾
	13				
	14	FI 4 status			FI8 status ¹⁾
15					
FI status	Frequency inverter status, Array [-01] Bit 8...Bit 15, or Array [-02] Bit 0 ... Bit 15:				
	Bit "High"	Bit "Low"	Meaning		
	0	0	Frequency inverter "offline"		
	0	1	Unknown frequency inverter		
	1	0	Frequency inverter "online"		
	1	1	Frequency inverter lost or switched off		
Status error codes	Status error code	Bit 6	Bit 5	Bit 4	Meaning
	FU_FAULT-101	0	0	X	
	FU_FAULT_102	0	X	0	PROFINET timeout
	FU_FAULT_103	0	X	X	Process data (STW) timeout
	FU_FAULT_104	X	0	0	CAN hardware error
	FU_FAULT_105	X	0	X	Ethernet No Link
	FU_FAULT_106	X	X	0	IO Hardware error
	FU_FAULT_107	X	X	X	Safe hardware error
	Example: Bit 4 = 0, Bit 5 = 1, Bit 6 = 0 → PROFINET timeout (E10.2)				

1) Not available.

P174	Digital input status	
Display range	0...65535 (0000 0000 0000 0000...1111 1111 1111 1111b)	
Bus interface	SK CU4-PNS, SK TU4-PNS	
Description	Display of the actual switching status of the digital bus interface inputs.	
Display values	Bit	Meaning
	0	Safe Input 1 (SI1) of the bus interface
	1	Safe Input 2 (SI2) of the bus interface
	2-7	-
	8	SLS F-Host
	9	SLS Bit0 F-Host
	10	SLS Bit1 F-Host
	11	SSR F-Host
	12	SDI_P F-Host
	13	SDI_N F-Host
	14	SOS F-Host
	15	-
P175	Relay status	
Display range	0...31 (00000...11111b)	
Bus interface	SK CU4-PNS, SK TU4-PNS	
Description	Display of the actual switching status of the relay outputs of the bus interface.	
Display values	Bit	Meaning
	0	Safe Output 1 (SO1) of the bus interface
	1	Safe Output 2 (SO2) of the bus interface
	2	Safe Output 3 (SO3) of the bus interface
	3	Clock output 1 (Clock1) of the bus interface
	4	Clock output 2 (Clock2) of the bus interface

P176	Process data Bus In		
Display range	-32768...32767		
Arrays	[-01] = Bus module outputs		
	[-02] = Control word	[-03]...[-07] = Setpoint 1...5 ¹	to F11
	[-08] = Control word	[-09]...[-13] = Setpoint 1...5 ¹	to F12
	[-14] = Control word	[-15]...[-19] = Setpoint 1...5 ¹	to F13
	[-20] = Control word	[-21]...[-25] = Setpoint 1...5 ¹	to F14
	[-26] = Control word	[-27]...[-31] = Setpoint 1...5 ¹	to F15 ²
	[-32] = Control word	[-33]...[-37] = Setpoint 1...5 ¹	to F16 ²
	[-38] = Control word	[-39]...[-43] = Setpoint 1...5 ¹	to F17 ²
	[-44] = Control word	[-45]...[-49] = Setpoint 1...5 ¹	to F18 ²
		¹ Setpoints 4 and 5 are not available.	
	² Not available.		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of data received from the IO-Controller.		

P177	Process data Bus Out		
Display range	-32768...32767		
Arrays	[-01] = Bus module inputs		
	[-02] = Status word	[-03]...[-07] = Actual value 1...5 ¹	from FI1
	[-08] = Status word	[-09]...[-13] = Actual value 1...5 ¹	from FI2
	[-14] = Status word	[-15]...[-19] = Actual value 1...5 ¹	from FI3
	[-20] = Status word	[-21]...[-25] = Actual value 1...5 ¹	from FI4
	[-26] = Status word	[-27]...[-31] = Actual value 1...5 ¹	from FI5 ²
	[-32] = Status word	[-33]...[-37] = Actual value 1...5 ¹	from FI6 ²
	[-38] = Status word	[-39]...[-43] = Actual value 1...5 ¹	from FI7 ²
	[-44] = Status word	[-45]...[-49] = Actual value 1...5 ¹	from FI8 ²
	¹ Setpoints 4 and 5 are not available.		
	² Not available.		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the data sent from the bus interface to the IO-Controller.		


7.1.4 PROFINET IO information parameters

PROFINET IO information parameters are used to display statuses and settings which are specific to the field bus.

P180	PPO Type		
Display range	0...16		
Arrays	[-01] = Slot 0 (DAP)		
	[-02] = Slot 1 (SAFE)		
	[-03] = Slot 2 (bus interface)		
	[-04]...[-07] = Slot 3...6 (FI1...4)		[-08]...[-11] = Slot 7...10 (FI5...8) ¹
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the currently assigned PPO type		
Note	The PPO type is assigned via the PROFINET IO configuration software.		
Display values	Value	Meaning	
	0 - 2	-	
	3	Empty slot	
	4	Reserved slot	
	5	DIG-IO	Process data for bus interface
	6	PPO3	Process data for frequency inverter
	7	PPO4	Process data for frequency inverter
	8	PPO6	Process data for frequency inverter
	9	PPO1	Process/parameter data for frequency inverter
	10	PPO2	Process/parameter data for frequency inverter
	11	DIG-IN	Process data for bus interface
	12 – 15	-	
	16	PnSafe	Process/parameter data for PROFIsafe bus interface

1) Not available.

P181	MAC address			
Display range	0...255			
Arrays	[-01]...[-03] = PROFINET identifier [-04]...[-06] =Manufacturer identifier (Getriebebau NORD GmbH & Co. KG)			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display of the unique MAC address of the bus interface.			
P185	Present IP address			
Display range	0...255			
Arrays	[-01]...[-04]			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display of the currently set bus interface IP address.			
Note	The IP address which is displayed here may deviate from the IP address which is set in parameter P160 (in case of addressing by the IO controller).			

P186	Present IP subnet mask			
Display range	0...255			
Arrays	[-01]...[-04]			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display of the currently set bus interface sub-net mask.			
Note	The sub-net mask which is displayed here may deviate from the sub-net mask which is set in parameter P161 (in case of addressing by the IO controller).			
P187	Present IP Gateway			
Display range	0...255			
Arrays	[-01]...[-04]			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display of the currently set IP address (parameter P164) for the gateway function of the bus interface.			
P190	DIP switch status			
Display range	0...8191			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display of the current settings of DIP switches 2...12 on the bus interface. DIP switch configuration  Technical Information/Data Sheet for the bus interface.			
Note	DIP switch 1 :	used as the termination resistor for the NORD system bus and is depicted as "0".		
	DIP switches 2...9:	F-address		
	DIP switches 10...12:	used to set the access rights for remote maintenance (NORD CON software via TCP/UDP):		
	DIP 10 =	TCP/UDP Write access to parameter		
	DIP 11 =	TCP/UDP control possible		
	DIP 12 =	TCP/UDP encryption active		

7.1.5 PROFIsafe standard parameters

Field-bus specific safety settings of the bus interface are made via the PROFIsafe standard parameters.

P800	I/O operating mode									
Setting range	0...1									
Arrays	[-01] = DigIn SI1 and SI2 [-02] = DigOut SO1 and SO2									
Factory setting	{ [-01] = 0 } { [-02] = 0 }									
Bus interface	SK CU4-PNS, SK TU4-PNS									
Description	Combination of the two digital inputs SI1 and SI2 (Array [-01]) and/or the two digital outputs SO1 and SO2 (Array [-02]) to form a two channel input/output.									
Setting values	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Single channel</td> </tr> <tr> <td>1</td> <td>Two channel</td> </tr> </tbody> </table>				Value	Meaning	0	Single channel	1	Two channel
Value	Meaning									
0	Single channel									
1	Two channel									
Note	<ul style="list-style-type: none"> For combination of the two digital inputs SI1 and SI2, both inputs must be switched within the set discrepancy time (P803) in order to be recognised as an input signal. For combination of the two digital outputs SO1 and SO2 both outputs must be switched simultaneously by the system. 									
P801	Error response									
Setting range	0...1									
Factory setting	{ 0 }									
Bus interface	SK CU4-PNS, SK TU4-PNS									
Description	Set error response: Passivation of the bus interface or the relevant channel. With passivation of the bus interface (value "0") the entire bus interface (SO1, SO2 and SO3) is passivated if an error is detected. With passivation of the channel (value "1") only the affected channel is passivated and all other channels are not affected.									
Setting values	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Bus interface</td> </tr> <tr> <td>1</td> <td>Channel</td> </tr> </tbody> </table>				Value	Meaning	0	Bus interface	1	Channel
Value	Meaning									
0	Bus interface									
1	Channel									
Note	With enabling of channel passivation, an error in the encoder evaluation only results in a message to the controller which is responsible for the error response.									

P802	Channel activation		
Setting range	0...1		
Arrays	[-01] = SI1	[-04] = SO2	[-07] = CLOCK 2
	[-02] = SI2	[-05] = SO3	
	[-03] = SO1	[-06] = CLOCK 1	
Factory setting	{ [-01]...[-07] = 0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Select (enable) the inputs and outputs which are to be used		
Setting values	Value	Meaning	
	0	Off	A signal at the input results in an error. An OSSD output cannot be switched, which results in an error, if this is not accessed by the safety PLC.
	1	On	Input signals are read in and transmitted to the controller. Output signals are given to the OSSD outputs.
Note	Input and output channels can only be used if they have been enabled. Switching on inputs or outputs without enabling results in an error.		

P803	Discrepancy time		
Setting range	0...30000 ms		
Factory setting	{ 10 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Set the discrepancy time for two channel mode (P800 I/O mode) for digital inputs SI1 and SI2.		
Note	<p>Example 1: Safe input in the "On" state A Low level on one channel sets the input to the "Off" state. At the same time, discrepancy monitoring starts. A Low level must be detected on both channels within the set time, otherwise a discrepancy error is reported. To acknowledge the error, a Low level must be detected on both channels.</p> <p>Example 2: Safe input in the "Off" state A High level on one channel starts discrepancy monitoring. A High level must be detected on both channels within the set time, otherwise a discrepancy error is reported. To acknowledge the error, High level must be detected on both channels.</p>		

P804	OSSD pulse																							
Setting range	0...8																							
Factory setting	{ 0 }																							
Bus interface	SK CU4-PNS, SK TU4-PNS																							
Description	Set the pulse width for testing the outputs. To test the outputs, the pulses are sent with a cycle of 50 ms on the output signal and read back.																							
Setting values	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>300 µs</td> </tr> <tr> <td>1</td> <td>400 µs</td> </tr> <tr> <td>2</td> <td>500 µs</td> </tr> <tr> <td>3</td> <td>600 µs</td> </tr> <tr> <td>4</td> <td>800 µs</td> </tr> <tr> <td>5</td> <td>1000 µs</td> </tr> <tr> <td>6</td> <td>1200 µs</td> </tr> <tr> <td>7</td> <td>1500 µs</td> </tr> <tr> <td>8</td> <td>2000 µs</td> </tr> </tbody> </table>				Value	Meaning	0	300 µs	1	400 µs	2	500 µs	3	600 µs	4	800 µs	5	1000 µs	6	1200 µs	7	1500 µs	8	2000 µs
Value	Meaning																							
0	300 µs																							
1	400 µs																							
2	500 µs																							
3	600 µs																							
4	800 µs																							
5	1000 µs																							
6	1200 µs																							
7	1500 µs																							
8	2000 µs																							
Note	The selected pulse width depends on the devices which are controlled by the safe outputs of the bus interface. Select the pulse width so small that the pulse is not detected as a level change.																							

P805	Filter time			
Setting range	2...100 ms			
Factory setting	{ 2 }			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Set the filter time for digital inputs SI1 and SI2.			

P810	Encoders									
Setting range	0...1									
Factory setting	{ 0 }									
Bus interface	SK CU4-PNS, SK TU4-PNS									
Description	Switch the evaluation of the connected encoder on or off.									
Setting values	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Encoder Off</td> </tr> <tr> <td>1</td> <td>Encoder On</td> </tr> </tbody> </table>				Value	Meaning	0	Encoder Off	1	Encoder On
Value	Meaning									
0	Encoder Off									
1	Encoder On									
Note	An error is triggered if encoder evaluation is enabled, although no encoder is connected.									

P811	Speed ratio			
Setting range	0.01...100.00			
Factory setting	{ 1.00 }			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Set speed ratio "motor speed/encoder speed". If a connected encoder is not mounted directly on the motor shaft, a speed ratio /reduction ratio can be set to monitor the motor speed.			
Note	The product of the encoder resolution (P812), speed ratio (P811) and the set speed limit (P823 converted into revolutions per second) must not exceed the limit frequency of the system of 150000 (inc/s).			

P812	Encoder resolution																																											
Setting range	0...17																																											
Factory setting	{ 5 }																																											
Bus interface	SK CU4-PNS, SK TU4-PNS																																											
Description	Set the resolution of a connected encoder.																																											
Setting values	<table border="1"> <thead> <tr> <th>Value</th> <th>Meaning</th> <th>Value</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>500 pulses</td> <td>9</td> <td>-512 pulses</td> </tr> <tr> <td>1</td> <td>512 pulses</td> <td>10</td> <td>-1000 pulses</td> </tr> <tr> <td>2</td> <td>1000 pulses</td> <td>11</td> <td>-1024 pulses</td> </tr> <tr> <td>3</td> <td>1024 pulses</td> <td>12</td> <td>-2000 pulses</td> </tr> <tr> <td>4</td> <td>2000 pulses</td> <td>13</td> <td>-2048 pulses</td> </tr> <tr> <td>5</td> <td>2048 pulses</td> <td>14</td> <td>-4096 pulses</td> </tr> <tr> <td>6</td> <td>4096 pulses</td> <td>15</td> <td>-5000 pulses</td> </tr> <tr> <td>7</td> <td>5000 pulses</td> <td>16</td> <td>-8192 pulses</td> </tr> <tr> <td>8</td> <td>-500 pulses</td> <td>17</td> <td>8192 pulses</td> </tr> </tbody> </table>				Value	Meaning	Value	Meaning	0	500 pulses	9	-512 pulses	1	512 pulses	10	-1000 pulses	2	1000 pulses	11	-1024 pulses	3	1024 pulses	12	-2000 pulses	4	2000 pulses	13	-2048 pulses	5	2048 pulses	14	-4096 pulses	6	4096 pulses	15	-5000 pulses	7	5000 pulses	16	-8192 pulses	8	-500 pulses	17	8192 pulses
Value	Meaning	Value	Meaning																																									
0	500 pulses	9	-512 pulses																																									
1	512 pulses	10	-1000 pulses																																									
2	1000 pulses	11	-1024 pulses																																									
3	1024 pulses	12	-2000 pulses																																									
4	2000 pulses	13	-2048 pulses																																									
5	2048 pulses	14	-4096 pulses																																									
6	4096 pulses	15	-5000 pulses																																									
7	5000 pulses	16	-8192 pulses																																									
8	-500 pulses	17	8192 pulses																																									
Note	The product of the encoder resolution (P812), speed ratio (P811) and the set speed limit (P823 converted into revolutions per second) must not exceed the limit frequency of the system of (150000 inc/s).																																											

P820	Safety function											
Setting range	0...1											
Arrays	[-01] = SLS	[-04] = SDI negative										
	[-02] = SSR	[-05] = SOS										
	[-03] = SDI positive											
Factory setting	{ [-01]...[-05] = 0 }											
Bus interface	SK CU4-PNS, SK TU4-PNS											
Description	Switch safety functions SLS (Safe Limited Speed), SSR (Safe Speed Range), SDI-P (Safe Direction Positive), SDI-N (Safe Direction Negative) and SOS (Safe Operating Stop) On/Off.											
Setting values	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Value</th> <th style="width: 15%;">Meaning</th> <th style="width: 70%;"></th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td style="text-align: center;">Off</td> <td>Safety function is switched off</td> </tr> <tr> <td style="text-align: center;">1</td> <td style="text-align: center;">On</td> <td>Safety function is switched on.</td> </tr> </tbody> </table>			Value	Meaning		0	Off	Safety function is switched off	1	On	Safety function is switched on.
	Value	Meaning										
	0	Off	Safety function is switched off									
1	On	Safety function is switched on.										
Note	<ul style="list-style-type: none"> An error is triggered if a safety function is switched on without enabling of the connected encoder. In order to be able to use a safety function, this must also be enabled by the safety PLC via the F-Data (safety data). An error is triggered if a safety function is enabled without it having been switched on with this parameter. 											



P821	Activation time		
Setting range	0...60.0 s		
Arrays	[-01] = SLS-0	[-05] = SSR	
	[-02] = SLS-1	[-06] = SDI positive	
	[-03] = SLS-2	[-07] = SDI negative	
	[-04] = SLS-3	[-08] = SOS	
Factory setting	{ [-01]...[-08] = 0.0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Set the activation time of the safety function (P820 safety function). The activation time which is set defines the time interval between activation of the safety function by the safety PLC and the start of monitoring by the safety function.		

P822	Response time		
Setting range	0...60.0 s		
Arrays	[-01] = SLS-0	[-05] = SSR	
	[-02] = SLS-1	[-06] = SDI positive	
	[-03] = SLS-2	[-07] = SDI negative	
	[-04] = SLS-3	[-08] = SOS	
Factory setting	{ [-01]...[-08] = 0.0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	<p>Set the response time of the safety function (P820 Safety function).</p> <p>The response time which is set defines the time interval between the detection of an error and the triggering of an error by the safety function.</p> <p>The response time is implemented with an integration counter which integrates upwards and downwards, so that the set time may be overshoot or undershot.</p>		
P823	Speed limit		
Setting range	0...9999 rpm		
Arrays	[-01] = Max. SLS-0	[-05] = Max. SSR	
	[-02] = Max. SLS-1	[-06] = Min. SSR	
	[-03] = Max. SLS-2	[-07] = Max. SSM	
	[-04] = Max. SLS-3		
Factory setting	{ [-01]...[-07] = 0.0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	<p>Set the speed limits for the safety functions.</p> <p>The speed limit which is set specifies the speed above which an error is triggered by the safety function.</p>		
Note	<p>The product of the encoder resolution (P812), speed ratio (P811) and the set speed limit (P823 converted into revolutions per second) must not exceed the limit frequency of the system of 150000 (inc/s).</p>		

P824	Max. position error		
Setting range	0...9999 inc		
Arrays	[-01] = Position limit SDI-P	[-03] = Position limit SOS	
	[-02] = Position limit SDI-N		
Factory setting	{ [-01]...[-05] = 0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Set maximum position deviation for safety function. The position deviation which is set specifies the change of position above which an error is triggered by the safety function.		
P830	Save i-Parameter		
Setting range	0...65535		
Factory setting	{ 0 }		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Save the i-Parameter (settings for parameters P800...P824) in the flash memory. Saving of the i-Parameters is started with transmission of the i-Parameter checksum (CRC).		
Note	<ul style="list-style-type: none"> • If the CRC of the i-Parameter does not match the set i-Parameters, the setting is not saved. • Calculation of the i-Parameter CRC is performed automatically in the NORD CON software and can be read out via parameter P840 I-Para CRC. 		

7.1.6 PROFIsafe information parameters

PROFIsafe information parameters are used to display safety-specific statuses and settings.

P840	i-parameter CRC			
Display range	0/65536			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display i parameter checksum (CRC) of the bus interface.			
Note	The CRC is calculated automatically by the NORDCON software from the saved i-Parameters (P800...P824).			
P841	Actual error			
Display range	5700...5799			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display of the actual error present. For a list of possible error messages please refer to  Section 8.4.2.)			
Note	<ul style="list-style-type: none"> The fault is acknowledged automatically by the safety PLC as soon as the cause of the fault has been remedied. After this, the fault can only be seen via parameter P842 Last error. The error message is reset when the supply voltage is switched off. 			
P842	Last error			
Display range	5700...5799			
Bus interface	SK CU4-PNS, SK TU4-PNS			
Description	Display last error. For a list of possible error messages please refer to  Section 8.4.2).			
Note	<ul style="list-style-type: none"> An existing fault is acknowledged automatically by the safety PLC as soon as the cause of the fault has been remedied. The last fault is displayed in order to show the reason for the fault after it has been acknowledged. The error message is reset when the supply voltage is switched off. 			

P843	Software version
Display range	0.0...999.9
Bus interface	SK CU4-PNS, SK TU4-PNS
Description	Display of the software version of the PROFIsafe bus interface.

P844	Temperature
Display range	-40...120 °C
Arrays	[-01] = Master [-02] = Slave
Bus interface	SK CU4-PNS, SK TU4-PNS
Description	Display of the actual temperature of the PROFIsafe bus interface. The value which is displayed is the internally measured temperature of the two channel system (Master and Slave).

P845	Actual voltage
Display range	2.5...3.6 V
Arrays	[-01] = Master [-02] = Slave
Bus interface	SK CU4-PNS, SK TU4-PNS
Description	Display of the actual voltage of the PROFIsafe bus interface. The value which is displayed is the internally measured voltage of the two channel system (Master and Slave).

P846	DIP switch status		
Display range	0...255		
Arrays	[-01] = Master [-02] = Slave		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the DIP switch settings of the two channel system.		
Note	The DIP switch settings are read in separately for each channel. In case of deviation an error is triggered and the bus interface cannot be started,		
P847	Speed		
Display range	0...9999 rpm		
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the actual speed which is measured by the connected encoder.		
Note	The speed display is updated after a delay and cannot be used for control.		
P848	System error		
Display range	0...65535		
Arrays	[-01] = Number of errors	[-06] = Information 1	
	[-02] = Error number	[-07] = Information 2	
	[-03] = Information 1	[-08] = Error number	
	[-04] = Information 2	[-09] = Information 1	
	[-05] = Error number	[-10] = Information 2	
Bus interface	SK CU4-PNS, SK TU4-PNS		
Description	Display of the total umber of system errors and display of the last 3 system errors with information.		
Note	If more than 15 system errors have been triggered, the bus interface can no longer be used and must be replaced.		

7.2 Parameter settings on the frequency inverter

After connection and addressing of the bus interface, the additional parameters of the frequency inverter must be set as listed below. The additional parameters of the frequency inverter are used to set the bus interface, the pulse frequency and acknowledgement of errors.

A detailed description of the parameters can be found in the relevant manual for the frequency inverter.

Additional parameters

The following table contains a list of additional parameters which are relevant for the bus interface.

No.	Parameter name	Recommended setting			Comments
		SK CU4/SK TU4	SK TU3		
		SK 1x0E, SK 2xxE	SK 500E–SK 535E	SK 54xE	
P509	Source Control Word	"3" = System bus	"8" = Ethernet TU	"8" = Ethernet TU	SK 511E frequency inverters and above: Communication with the bus interface via the system bus is possible with setting "6" = CANopen.
P510	Setpoint source	"0" = Auto	"0" = Auto	"0" = Auto	If P509 is set to "3", "6" or "8"
P513	Telegram timeout	—	○ ¹	○ ¹	
P514	CAN bus baud rate	"5" = 250 kBaud	"5" = 250 kBaud	"5" = 250 kBaud	
P515	CAN address (Array [-01])	32, 34, 36 or 38	—*	—*	System bus address
P543	Actual bus value Arrays [-01]...[-03]	○ ²	○ ²	○ ²	Refer to the relevant frequency inverter operating manual
	Actual bus value Arrays [-04]...[-05]	—	—	○ ²	
P543	Actual bus value 1	—	○ ²	—	
P544	Actual bus value 2	—	○ ²	—	
P545	Actual bus value 3	—	○ ²	—	
P546	Function Bus setpoint Arrays [-01]...[-03]	○ ²	—	○ ²	Refer to the relevant frequency inverter operating manual
	Function Bus setpoint Arrays [-04]...[-05]	—	—	○ ²	
P546	Function Bus setpoint 1	—	○ ²	—	
P547	Function Bus setpoint 2	—	○ ²	—	
P548	Function Bus setpoint 3	—	○ ²	—	

* Only necessary if more than one frequency inverter is connected to bus interface .

○¹ Depending on the application: Change the settings according to the requirements of the application.

○² Depending on the function: Setting according to the required function(s) is necessary.

Information parameters

Information parameters are used to display current and archived error messages, as well as current operating states and settings.

The following table contains a list of information parameters which are relevant for the bus interface.

No.	Parameter name	SK TU3	SK CU4	SK TU4																																																									
P700	Current error	Array [-01]																																																											
	Current warning	Array [-02]																																																											
	Reason for switch-on block	Array [-03]																																																											
P701	Last fault																																																												
P740	Process data Bus In	No display if P509 is set to "0"																																																											
P741	Process data Bus Out																																																												
P744	Configuration																																																												
P745	Module version		—																																																										
P746	Module status	<p>Possible values:</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Initialisation (waiting for Application Relation AR)</td> </tr> <tr> <td>1</td> <td>Application Relation AR established</td> </tr> <tr> <td>2</td> <td>Reserved</td> </tr> <tr> <td>3</td> <td>Timeout (P151/P513)</td> </tr> <tr> <td>4</td> <td>Error 1</td> </tr> <tr> <td>5</td> <td>Error 2</td> </tr> <tr> <td>6</td> <td>Error 3</td> </tr> <tr> <td>7</td> <td>System bus Error / Warning</td> </tr> <tr> <td>8...15</td> <td>F11...F14 status</td> </tr> </tbody> </table> <p>Table of errors:</p> <table border="1"> <thead> <tr> <th colspan="3">Error</th> <th>Meaning</th> </tr> <tr> <th>3</th> <th>2</th> <th>1</th> <th></th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>X</td> <td>No error</td> </tr> <tr> <td>0</td> <td>X</td> <td>0</td> <td>PN timeout</td> </tr> <tr> <td>0</td> <td>X</td> <td>X</td> <td>Process data (STW) timeout</td> </tr> <tr> <td>X</td> <td>0</td> <td>0</td> <td>CAN hardware error</td> </tr> <tr> <td>X</td> <td>0</td> <td>X</td> <td>Ethernet No Link</td> </tr> <tr> <td>X</td> <td>X</td> <td>0</td> <td>IO Hardware error</td> </tr> <tr> <td>X</td> <td>X</td> <td>X</td> <td>Safe hardware error</td> </tr> </tbody> </table>		Bit	Meaning	0	Initialisation (waiting for Application Relation AR)	1	Application Relation AR established	2	Reserved	3	Timeout (P151/P513)	4	Error 1	5	Error 2	6	Error 3	7	System bus Error / Warning	8...15	F11...F14 status	Error			Meaning	3	2	1		0	0	X	No error	0	X	0	PN timeout	0	X	X	Process data (STW) timeout	X	0	0	CAN hardware error	X	0	X	Ethernet No Link	X	X	0	IO Hardware error	X	X	X	Safe hardware error	—	
Bit	Meaning																																																												
0	Initialisation (waiting for Application Relation AR)																																																												
1	Application Relation AR established																																																												
2	Reserved																																																												
3	Timeout (P151/P513)																																																												
4	Error 1																																																												
5	Error 2																																																												
6	Error 3																																																												
7	System bus Error / Warning																																																												
8...15	F11...F14 status																																																												
Error			Meaning																																																										
3	2	1																																																											
0	0	X	No error																																																										
0	X	0	PN timeout																																																										
0	X	X	Process data (STW) timeout																																																										
X	0	0	CAN hardware error																																																										
X	0	X	Ethernet No Link																																																										
X	X	0	IO Hardware error																																																										
X	X	X	Safe hardware error																																																										
P748	CANopen status	Displays the system bus status																																																											

8 Error monitoring and error messages

Bus interfaces and frequency inverters are equipped with monitoring functions and generate error messages in case of deviations from the normal operating state.

8.1 Bus operation monitoring function

Independent of the specific bus watchdogs, comprehensive monitoring functions are integrated into Getriebebau NORD GmbH & Co. KG frequency inverters and bus interfaces. With the aid of this "Timeout" monitoring, communication problems are detected, which are either related to general functionalities ("No bus communication") or are related to special modules ("Failure of a participant").

Monitoring of communication at the field bus level is primarily carried out via the bus interface. Field bus communication faults are registered in the bus interface. If an error at field bus level causes an error in the frequency inverter, the frequency inverter also displays a corresponding error. The frequency inverter itself does not monitor communication on the field bus level.

Monitoring of communication on the NORD system bus level (between the frequency inverter and the bus interface) is carried out by the frequency inverter. An error in the system bus communication is registered in both the bus interface and the frequency inverter and results in specific error messages.

Function	Parameter						
	Bus interface	SK CU4 and SK TU4 via NORD system bus			SK TU3 ¹⁾	SK TU3 via CANopen/NORD system bus ²⁾	
		Frequency inverters	SK 1x0E SK 2xxE	SK 511E ... SK 535E	SK 54xE ³⁾	SK 5xxE	SK 511E ... SK 535E
Field bus timeout		P151	P151	P151	P513	P513	P513
Optional monitoring (system bus timeout)		P120	P513	P120	— ⁴⁾	P513	P120
Bus interface error display		P170 (P700)	P170 (P700)	P170 (P700)	P170 ²⁾ P700	P170 P700	P170 P700
Error display for frequency inverter and communication errors between the frequency inverter and the bus interface.		P700	P700	P700	P700	P700	P700

1) Only for communication between the SK TU3 bus interface and the frequency inverter on which the bus interface is mounted.

2) Only for Ethernet-based bus interfaces

3) Connection for CANopen (Parameter **P509**)

4) Monitoring is automatic and cannot be set.

Information

Parameter P513

The setting ("0.1" = No error) of parameter **P513 Telegram timeout time** ensures that the frequency inverter ignores all communication errors on both the field bus and the system bus level. The frequency inverter maintains its operating status.




Figure 19: Examples of monitoring parameter settings – SK TU4 bus interface

Setting values for parameter **P509 Control word source**:

3 = System bus

6 = CANopen

8.2 Resetting error messages

There are several methods for resetting (acknowledging) an error message.

On the frequency inverter:

- Switch the mains voltage off and on again, or
- Enable the programmed digital input with parameter **P420 Digital inputs** (Setting 12 = Acknowledge error), or
- Switch off "Enable" on the frequency inverter (if no digital input is programmed) or
- Perform a bus acknowledgement, or
- Automatic error acknowledgement by activating parameter **P506 Auto. error acknowledgement**.


On the bus interface

The error message (via information parameter **P170**, [-01]) is automatically reset if the error is no longer active. Otherwise:

- Switch the voltage supply to the bus interface off and on again, or
- Acknowledge the error via the field bus.

Information

Acknowledging PROFIsafe errors

Processing of errors in the transmission of safety-relevant data differs from the processing of errors in the transmission of PROFINET IO data. For a detailed description see  Section 8.3 "Handling of errors in the bus interface".

Information

Archiving error messages

A field bus communication error (display via parameter **P170**) is only displayed as long as it is active. After the error has been remedied, the message is deleted and is archived as the last error message in parameter **P170**, Array [-02]. If the mains supply is interrupted before the error is remedied, the message is lost, i.e. it is not archived.

Information

Error display in the SimpleBox

A field bus communication error is displayed in the operating display of the SimpleBox SK CSX-3H by display of the error group number "E1000". The bus interface parameter **P170**, Array [-01] must be selected to determine the actual error.

8.3 Handling of errors in the bus interface

8.3.1 PROFINET IO

If an error occurs in the frequency inverters which are connected to the NORD system bus, or in the bus interface, the bus interface sends a diagnostic alarm as "incoming event" to the IO controller. The error value is coded as follows:

Error number (Value from P700 or P170) + 100 h = Alarm number of the diagnostic alarm

Example:

Error E10.3 "Timeout by P151/P513" occurs during operation (**P700**, Index 1 = 103). The bus interface sends a diagnostic alarm with the value "359" (= 100h + 103 = 256 + 103 = 359) to the IO controller.

Format	Error number	Alarm code	Alarm number
Decimal	10.3 = 103	256	103 + 256 = 359
Hexadecimal	67h	100h	167h

If an error has been remedied or acknowledged, a diagnostic alarm is sent as a "outgoing event", which resets the error in the IO controller.



Information

Loss of a connected frequency inverter

If the connection is lost between the bus interface and one of the frequency inverters which are connected to the NORD system bus, an alarm with the error number "1000" is sent to the diagnostic buffer of the IO controller (256 + 1000 = 1256). This error is not saved in P170, but rather is only used for information in case the shut-down of the connected frequency inverter is a part of the application.

Error messages which are generated by the frequency inverter are transferred from the bus module to the field bus level. They do not result in an error of the bus module.

8.3.2 PROFIsafe

If an error occurs in the frequency inverters which are connected to the NORD system bus, or in the bus interface, the bus interface sends a corresponding error code (see Section 8.4 "Error messages") to the F-Host. For the evaluation of errors, a differentiation is made between general errors and system errors.

General errors

General errors are divided into acknowledgeable errors and fatal errors. After the bus interface has detected an error on one or more inputs/outputs, depending on the setting of parameter **P801 Error response** either the channel or the entire bus interface is passivated.

For **passivation of the bus interface** the bus interface is set to a safe state (switch-off of all inputs and outputs). Failsafe values (Failsafe Values "0") are transmitted to the F-Host and the device status is set to "Fault" (bus interface in fault mode). An error which can be acknowledged would be automatically reset after the cause of the error had been remedied. Therefore, in the F-Host project, care must be taken that the bus interface does not start again automatically, but rather only after acknowledgement with a command from the F-Host ("Acknowledgement for Reintegration" according to the PROFIsafe specification).

With **channel passivation** the corresponding channel (OSSD1...OSSD3, CLOCK1, Clock2 or Encoder) is switched off. An acknowledgeable error is still present after the cause of the error has been remedied and must be acknowledged with a command from the F-Host (control byte data "F-Data In 3.7" acknowledge channel passivation).

If a fatal error occurs (e.g. due to a failed checksum check), all of the bus interface inputs and outputs are switched off. The error can only be reset by switching the power supply off and on again. The device status is set to "Fault" and "Active_FV" (device in a safe state, all channels passivated).

System error

System errors are triggered by malfunctions of the bus interface and cannot be influenced by the user. If a system error occurs, all of the bus interface inputs and outputs are switched off. The error can only be reset by switching the power supply off and on again. The device status is set to "Fault" and "Active_FV" (device in a safe state, all channels passivated).

Frequent occurrence of system errors is a symptom of a defective bus interface. After the occurrence of a maximum of 15 system errors, the bus interface is automatically shut down and starts with a fatal error when it is restarted. In this case, the bus interface must be replaced.

The number of system errors which have occurred is displayed via parameter **P848 System errors**.

8.4 Error messages

8.4.1 PROFINET IO

Error messages from the bus interface can be read out via parameter **P170** of the bus interface (Array [-01] = Actual error, Array [-02] = Previous error).

Error	Meaning	Comments
100.0	EEPROM error	EMC fault, bus interface defective
101.0	System bus 24 V missing	No 24 V voltage on bus, connections not correct
102.0	Bus timeout P151	By means of timeout supervision parameter P151
103.0	System bus Off	No 24 V voltage on bus, connections not correct
550.0	General configuration error	No Ethernet connection (see E10.5)
550.2	Hardware error System bus	EMC fault (see E10.6)
550.3	SAFE hardware error	Error in the safety module (see E10.7)
550.4	FI lost	Connection to system bus participant (FI) lost
550.5	AR lost	PROFINET telegram failure, connection to the IO controller lost (see E10.2)
564.0	MAC address error	MAC address defective

Error messages which occur in relation to the bus interface are depicted as follows in the error memory of the frequency inverter (Parameter **P700** and **P701**).

Error (E010)	Meaning	Comments
10.0	Connection error	<ul style="list-style-type: none"> • Contact to bus interface lost
10.2	PROFINET telegram failure	<ul style="list-style-type: none"> • Check physical bus connections • Check the status of the PROFINET IO controller
10.3	Timeout through P151	<ul style="list-style-type: none"> • System bus monitoring has triggered. <ul style="list-style-type: none"> – Check time setting parameter P151 • Telegram transfer is faulty. <ul style="list-style-type: none"> – Reception of cyclic telegrams • Check physical bus connections
10.5	General PROFINET configuration error	<ul style="list-style-type: none"> • Connection to the Ethernet lost.
10.6	System bus hardware error	<ul style="list-style-type: none"> • Remedy EMC fault
10.7	Hardware error, Safe bus interface	<ul style="list-style-type: none"> • An error has occurred in the safe hardware. <ul style="list-style-type: none"> – Remedy EMC fault – Restart the bus interface
10.8	Timeout connection error	<ul style="list-style-type: none"> • Connection between bus interface and frequency inverter interrupted due to timeout.
10.9	Module missing P120	<ul style="list-style-type: none"> • The module entered in parameter P120 is not available.

8.4.2 PROFIsafe

For error messages which occur on transmission of safety-relevant data, a four digit error code (error code range 5711...5799) is sent to the F-Host.

On the bus interface, the error messages are indicated with the red "FE" (Failsafe Error) LED by means of a flashing code (only tens and units of the error code).

Flashing code of the two digit error code





Figure 20: Flashing code – Error example "5713" (Invalid host address)

Item	Flashing code	Meaning
1	Strobe	Three consecutive pulses, pulse length = 400 ms each (200 ms On / 200 ms Off)
2	Pause	LED 2 seconds Off
3	Error code for the 10s decimal place	The LED is switched with a cycle of 1 second (1 second On, 1 second Off)
4	Error code for the 1s decimal place	

A detailed description of all bus interface LEDs can be found in the  Technical Information.

PROFIsafe error messages

F parameter errors

Error code	Type ₁	Name	Meaning	Remedy
5711	q	Mismatch of F-destination address	The F-destination address set via DIP switches on the bus interface and parameterized in the IO Controller (F_Dest_Add) do not match.	Change the DIP switch setting or parameterised destination address.
5712	q	Invalid F-destination address	The set F-destination address is invalid, only F-destination addresses 1 to 255 are permitted.	Change the DIP switch setting or the parameterised destination address.
5713	q	Invalid host address	The source address which is parameterised in the controller is invalid.	Change the source address.
5714	q	Watchdog time is zero	A watchdog time of zero is invalid.	Set a valid watchdog time in the controller.
5715	q	Incorrect F-SIL	The F-SIL level which is set in the controller is higher than the F-SIL level which is supported by the bus interface.	Change the F-SIL level.
5716	q	Incorrect F-Par version	The F-Par version which is set in the controller is not compatible with the bus interface.	Change the F-Par version.
5717	q	Incorrect F-Parameter checksum.	The F-Parameter checksum (F-Par-CRC) which is determined and transmitted by the controller is not correct.	This error occurs, e.g. if the F-Parameter which is set does not correspond to the specifications.
5718	q	General F-Parameter error		Check the F-Parameter in the controller and re-set.

Error code	Type ¹	Name	Meaning	Remedy
5719	q	Incorrect i-parameter checksum	The checksum of the saved i-Parameter which is calculated in the bus interface and the i-Parameter checksum which is entered in the controller program do not match.	Check the i-Parameters and enter the calculated i-Parameter value (P840) in the controller program.
5721	q	The CRC length deviates from the pre-set value		Check the setting of the F-Parameters and correct as necessary.
5722	f	i-parameters have been changed.	The i-Parameters in the bus interface have been changed.	Re-boot the bus interface to adopt the changed i-parameters.
5723	f	Different i-Parameter checksum	The transmitted i-Parameter checksum does not match the newly transmitted i-Parameters.	Re-transmit the i-Parameters, so that they are adopted by the bus interface. Then restart the bus interface.
5724	f	Incorrectly calculated i-Parameter checksum	The checksum of the saved i-Parameter and the saved i-parameter checksum do not match.	Reload the i-Parameters and save.
5725	f	Incorrect F-Parameter telegram		Check the setting of the F-Parameters and correct as necessary.
5726	f	Error when reading in the DIP switch	The DIP switch may be set to zero (invalid value). If this error occurs frequently, the bus interface hardware is defective and the bus interface must be replaced.	Restart the bus interface so that the DIP switch setting is read in again.

¹ f = Fatal error; the device must be switched off and the cause of the error eliminated.

q = Acknowledgeable error; the error is reset when the cause of the error has been remedied.

Errors at inputs

Error code	Type ¹	Name	Meaning	Remedy
5731	q	Different input signals on both channels (discrepancy test)	If the operating mode parameter P800 is set to "Two channel", the same state must be set at both inputs within the parameterised discrepancy time (P803). An error is triggered if this is not the case.	The error is reset if both channels are in the "Off" state. After this, the bus interface can be re-integrated.

¹ q = Acknowledgeable error; the error is reset when the cause of the error has been remedied.

Errors at outputs

Error code	Type ¹	Name	Meaning
5732	q	Diagnostic error (OSSD) at Output 1	A diagnostic error occurs in case of a short circuit, a cross circuit or an internal error. The error is present for at least 5 sec. Once the cause of the error has been remedied, the error is reset and the bus interface can be re-integrated.
5733	q	Diagnostic error (OSSD) at Output 2	
5734	q	Diagnostic error (OSSD) at Output 3	
5735	q	Diagnostic error (OSSD) at clock Output 1	
5736	q	Diagnostic error (OSSD) at clock Output 2	

¹ q = Acknowledgeable error; the error is reset when the cause of the error has been remedied.

i-Parameter error (parameterisation error)

Error code	Type ₁	Name	Meaning	Remedy
5741	q	iPar error OSSD1 channel activation	Output SO1 is activated, although channel activation has not been set (Parameter P802 , Array 3).	As soon as the cause of the error has been remedied, the bus interface can be re-integrated.
5742	q	iPar error OSSD2 channel activation	Output SO2 is activated, although channel activation has not been set (parameter P802 , Array 4).	
5743	q	iPar error OSSD3 channel activation	Output SO3 is activated, although channel activation has not been set (parameter P802 , Array 5).	
5744	q	iPar error Clock Cycle 1 channel activation	CLOCK 1 is activated, although channel activation has not been set (parameter P802 , Array 6).	
5745	q	iPar error Clock Cycle 2 channel activation	CLOCK 2 is activated, although channel activation has not been set (parameter P802 , Array 7).	
5746	q	iPar error SI1 channel activation	A signal is present at input SI1, although channel activation has not been set (parameter P802 , Array 1).	
5747	q	iPar error SI2 channel activation	A signal is present at input SI2, although channel activation has not been set (parameter P802 , Array 2).	

8 Error monitoring and error messages

Error code	Type ₁	Name	Meaning	Remedy
5748	f	iPar error i-Parameter channel activation	Parameter P802 Channel activation is incorrectly parameterised (outside of the limits).	Reset the i-Parameters and restart the bus interface.
5749	F	iPar error OSSD signal pulse length	Parameter P804 OSSD pulse is incorrectly parameterised (outside of the limits).	
5751	f	iPar error Digital Input filter time	Parameter P805 Filter time is incorrectly parameterised (outside of the limits).	
5752	F	iPar error Single/Two channel operation	Parameter P805 I/O mode is incorrectly parameterised (outside of the limits).	
5753	f	iPar error input time discrepancy	Parameter P803 Discrepancy time is incorrectly parameterised (outside of the limits).	
5754	f	iPar error Passivation	Parameter P801 Error response time is incorrectly parameterised (outside of the limits).	
5755	f	iPar error encoder parameter	Parameter P810 Encoder , parameter P811 Speed ratio or parameter P812 Encoder resolution is incorrectly parameterised (outside of the limits).	
5756	f/q	iPar error SLS activation	<ul style="list-style-type: none"> Parameter P820 Safety function SLS (Array 1) is deactivated or the safety function SLS is activated and parameter P810 Encoder is deactivated. 	Reset the i-Parameters and restart the bus interface.
			<ul style="list-style-type: none"> Parameter P820 Safety function SLS (Array 1) is deactivated and is accessed by the controller via the F-Data. 	As soon as the error has been remedied, the bus interface can be re-integrated.

Error code	Type ₁	Name	Meaning	Remedy
5757	f/q	iPar error SSR activation	<ul style="list-style-type: none"> Parameter P820 Safety function SSR (Array 2) is deactivated or the safety function SSR is activated and parameter P810 Encoder is deactivated. 	Reset the i-Parameters and restart the bus interface.
			<ul style="list-style-type: none"> Parameter P820 Safety function SSR (Array 2) is deactivated and is accessed by the controller via the F-Data. 	As soon as the error has been remedied, the bus interface can be re-integrated.
5758	f/q	iPar error SDI-P activation	<ul style="list-style-type: none"> Parameter P820 Safety function SDS positive (Array 3) is deactivated or the safety function SDS positive is activated and Parameter P810 Encoder is deactivated. 	Reset the i-Parameters and restart the bus interface.
			<ul style="list-style-type: none"> Parameter P820 Safety function SDI positive (Array 3) is deactivated and is accessed by the controller via the F-Data. 	As soon as the error has been remedied, the bus interface can be re-integrated.
5759	f/q	iPar error SDI-N activation	<ul style="list-style-type: none"> Parameter P820 Safety function SDS negative (Array 4) is deactivated or the safety function SDS negative is activated and parameter P810 Encoder is deactivated. 	Reset the i-Parameters and restart the bus interface.
			<ul style="list-style-type: none"> Parameter P820 Safety function SDI negative (Array 4) is deactivated and is accessed by the controller via the F-Data. 	As soon as the error has been remedied, the bus interface can be re-integrated.

8 Error monitoring and error messages

Error code	Type ¹	Name	Meaning	Remedy
5761	f/q	iPar error SOS activation	<ul style="list-style-type: none"> Parameter P820 Safety function SOS (Array 5) is deactivated or the safety function SOS is activated and parameter P810 Encoder is deactivated. 	Reset the i-Parameters and restart the bus interface.
			<ul style="list-style-type: none"> Parameter P820 Safety function SOS (Array 5) is deactivated and is accessed by the controller via the F-Data. 	As soon as the error has been remedied, the bus interface can be re-integrated.
5762	f	iPar error Activation time	Parameter P821 Activation time is incorrectly parameterised (outside of the limits).	Reset the i-Parameters and restart the bus interface.
5763	f	iPar error Response time	Parameter P822 Response time is incorrectly parameterised (outside of the limits).	
5764	f	iPar error Speed	Parameter P823 Speed is incorrectly parameterised (outside of the limits) or the speed "Min. SSR" (P823 , Array 6) is greater than the speed "Max. SSR" (P823 , Array 5).	
5765	f	iPar error Tolerance	Parameter P824 Max. position error is incorrectly parameterised (outside of the limits).	
5766	f	iPar error Limit frequency exceeded	The combination of the set speed ratio P811 , the encoder resolution P812 and the limit speed P823 results in a higher value than the permitted limit frequency for the encoder circuit.	The following condition must be complied with: $P811 * P812 [\text{number of pulses}] * P823 / 60 < 150000$ After this, reset the i-Parameters and restart the bus interface.

¹ f = Fatal error; the device must be switched off and the cause of the error eliminated.

q = Acknowledgeable error; the error is reset when the cause of the error has been remedied.

Encoder errors

Error code	Type ¹	Name	Meaning	Remedy
5781	q	SLS error	The SLS speed which has been set and selected by the controller has been exceeded.	As soon as the cause of the error has been remedied, the bus interface can be re-integrated.
5782	q	SSR error	A set SSR Speed has been exceeded or undershot.	
5783	q	SDI_P error	A negative direction has been detected by the encoder and the number of counted values is larger than the set tolerance (P824).	
5784	q	SDI_N error	A positive direction has been detected by the encoder and the number of counted values is larger than the set tolerance (P824).	
5785	q	SOS error	The number of values counted by the encoder larger than the set tolerance(P824).	

¹ q = Acknowledgeable error; the error is reset when the cause of the error has been remedied.

System error

Error code	Type ¹	Name	Meaning	Remedy
5771	f	Temperature outside of specification	The measured temperature has exceeded the limits (< -25 °C or > 75 °C)	Restart the bus interface.
5772	q	Encoder safety condition breached	An error has been detected at the encoder connection.	Check the wiring. An encoder must be connected if an encoder is enabled (P810). As soon as the cause of the error has been remedied, the bus interface can be re-integrated.
5773	f	The SYNC signal has not been reduced to "Low" in the meantime	An error has occurred during synchronisation between the two processors of the bus interface.	Restart the bus interface.
5774	f	Supply voltage error	The supply voltage is too high or too low	The supply voltage is specified for the range between 19.2V and 30V. Cause of error: <ul style="list-style-type: none"> • Voltage is not within the permissible range, • Voltage increase too slow • Voltage decrease too slow
5775	f	Supply voltage error	The supply voltage is too high or too low	See error code 5774
5776	f	Speed difference error	The difference between the speeds, measured by the two processors is too high.	<ul style="list-style-type: none"> • Strictly comply with the specifications for connecting the module (ensure EMC). • Restart the bus interface. • A renewed occurrence of the error indicates a defect in the bus interface.
5791	f	System error saved in flash memory	A system error has been triggered and is saved.	Restart the bus interface. If more than 15 system errors have been triggered, the bus interface can no longer be used and must be replaced.

Error code	Type ¹	Name	Meaning	Remedy
5792	f	Maximum number of system errors reached	More than 15 system errors have occurred on the bus interface.	Replace the bus interface, as a large number of system errors indicate a hardware defect.
5797	f	Flash memory access error (does not trigger a system error, because saving is not possible)	A flash memory access error cannot be saved.	Restart the bus interface. The bus interface must be replaced if this error occurs frequently.
5799	f	Reserved for PROFINET		

¹ f = Fatal error; the device must be switched off and the cause of the error eliminated.

q = Acknowledgeable error; the error is reset when the cause of the error has been remedied.

9 Appendix

9.1 Repair information

In order to keep repair times as short as possible, please state the reasons for the return of the device and at least one contact partner in case of queries.

In case of repairs, please send the device to the following address:

NORD Electronic DRIVESYSTEMS GmbH

Tjüchkampstraße 37
26606 Aurich, Germany

i Information

Third party accessories

Before returning a bus interface and/or a frequency inverter, please remove any external accessories such as mains cables, potentiometers, external displays, etc., which were not supplied by Getriebebau NORD GmbH & Co. KG. No liability can be accepted by Getriebebau NORD GmbH & Co. KG for devices which are returned with third party accessories.

i Information

Accompanying document

Please use the filled-in accompanying document for returns, You can find this on our homepage www.nord.com or directly under the link [Warenbegleitschein](#).

For queries about repairs, please contact:

Getriebebau NORD GmbH & Co. KG

Tel.: +49 (0) 45 32 / 289-2515
Fax: +49 (0) 45 32 / 289-2555

9.2 Service and commissioning information

In case of problems, e.g. during commissioning, please contact our Service department:

☎ +49 4532 289-2125

Our Service department is available 24/7 and can help you best if you have the following information about the device and its accessories to hand:

- Type designation,
- Serial number,
- Firmware version

9.3 Documents and software

Documents and software can be downloaded from our website www.nord.com.

Other applicable documents and further information

Documentation	Contents
TI 275271014	Technical Information/Data Sheet for bus interface SK CU4-PNS
TI 275281116	Technical Information/Data Sheet for bus interface SK TU4-PNS with RJ45 connection (for IP55 devices)
TI 275281166	Technical Information/Data Sheet for bus interface SK TU4-PNS-C with RJ45 connection (for IP66 devices)
TI 275281216	Technical Information/Data Sheet for bus interface SK TU4-PNS-M12 with M12 connection extension (for IP55 devices)
TI 275281266	Technical Information/Data Sheet for bus interface SK TU4-PNS-M12-C M12 connection extension (for IP66 devices)
BU 0200	Manual for frequency inverter SK 2xxE (NORDAC FLEX)
BU 0230	Functional safety manual for frequency inverter SK 2xxE (NORDAC FLEX)
BU 0235	Functional safety manual for frequency inverter SK 2x0E-FDS (NORDAC LINK)
BU 0250	Manual for frequency inverter SK 2x0E-FDS (NORDAC LINK)
BU 0000	Manual for use of NORDCON software
BU 0040	Manual for use of NORD parameterisation units

Software

Software	Description
GSDML file	Device description file for PROFINET IO/PROFIsafe configuration software
NORDCON	Parametrisation and diagnostic software

Certificates

Certificate	Description
C330705	Certificate for "Fail-safe I/O module"

Key word index

A	
Accompanying document	123
Acknowledgement for Reintegration	110
Activation time (P821)	98
Actual (P841)	101
Actual error (P170)	86
Actual value	
IW	50
Actual values	57
Actual voltage (P845)	102
Addressing the bus interface	40, 43, 46
Application data	48
B	
Binary transmission	57
Black Channel	14
Bus address	
DIP switch	40
Bus master	
Integration	40, 41, 50
Bus node	36
C	
CAN bus address (P515)	36
CAN bus baud rate (P514)	36
CAN-ID	36
CANopen	34
Channel activation (P802)	95
Checksum check (CRC)	41
Commissioning	40, 45
Configuration level (P172)	86
Connection:	40
Control bit	51
Control word	51, 55
STW	50
D	
Data record transfer	
Examples	68
Data records	
Format	64
Parameter orders	63
Data transmission	47
Device description file	42
Device name (P162)	84
Dip switch status (P190)	93
DIP switch status (P846)	103
Discrepancy time (P803)	95
Documents	
other applicable	124
E	
Electrician	11
Encoder (P810)	96
Encoder resolution (P812)	97
Error (PROFIsafe)	
General	110
System error	110
Error messages	41, 86, 106
Bus interface	110, 111
Frequency inverter	111
from frequency inverters	109
PROFIsafe	112
Reset	108
Error monitoring	41, 86, 106
Error response (P801)	94
Extra functions	104
F	
Factory settings (P152)	81
F-Address (code name)	44
F-Data	47
F-Data exchange	71
F-Data transmission	41, 47, 71
F-Device (safety field device)	14
F-Host (safety controller)	14
Field bus address	43
Filter time (P805)	96
F-Parameters	74

I		parameter value PWE2
I/O operating mode(P800).....	94	Error messages.....
Information parameter.....	105	ParameterBox.....
IO		Parameterisation
controller.....	12	PPO1 or PPO2.....
device.....	12	Parameters
supervisor.....	12	Bus interface.....
IP address		Percentage transfer.....
(P160).....	83	Permissible writing cycles.....
IP Gateway (P164).....	85	PKW area.....
IP sub-net mask (P161).....	83	PPO type PPO1.....
i-parameter CRC(P840).....	101	PPO type PPO2.....
L		PPO type PPO3.....
Last error (P842).....	101	PPO type PPO4.....
M		PPO type PPO6.....
MAC address (P181).....	92	PPO types.....
Max. position error (P824).....	100	PPO types (Structure).....
Min. system bus cycle (P153).....	81	PPO-Type (P180).....
Module status (P173).....	87	Present IP address (P185).....
Monitoring functions.....	106	Present IP Gateway (P187).....
Monitoring parameter.....	107	Present IP sub-net mask (P186).....
N		Process data.....
NORD CON computer.....	34	Process data Bus In (P176).....
NORD CON software.....	38	Process data bus Out (P177).....
NORD system bus.....	7, 34	Process data telegrams.....
O		PROFIBUS profile.....
Order label.....	65	PROFINET IO-Controller.....
OSSD pulse (P804).....	96	PROFIsafe F-Host.....
P		R
Parameter		Records.....
Frequency inverters.....	104	Re-integratable.....
index.....	67	Relay status (P175).....
numbers.....	64	Remote maintenance.....
order.....	62	Repair.....
response.....	62	Response label.....
Parameter data.....	47	Response time (P822).....
Parameter data transmission.....	47, 60, 61, 63	Returns.....
Parameter numbers.....	63	S
Parameter settings		Safety function (P820).....
Frequency inverters.....	104	Save i-Parameter(P830).....
		SDI-N (Safe Direction Negative).....

SDI-P (Safe Direction-Positive).....	31	Status machine	
Set relay (P150).....	79	Frequency inverter	53
Setpoint		Status of digital in. (P174).....	88
SW	50	Status word	52, 56
Setpoint specification		ZSW.....	50
Example	77	System error (P848).....	103
Setpoints.....	57	T	
SimpleBox.....	37	TB-IO access (P154)	82
SLS (Safely Limited Speed)	29	Telegram timeout (P513)	106
Software.....	124	Temperature (P844).....	102
Software version		Test alarm (P163)	84
P171	86	Timeout	106
SOS (Safe Operating Stop)	32	Timeout for external bus (P151)	80
Speed (P847)	103	Topology	16
Speed limit (P823)	99	Transfer of process data	42, 47, 50, 61
Speed ratio (P811)	97	Transmission of positions	58
SSM (Safe Speed Monitoring).....	33	U	
SSR (Safe Speed Range)	30	USS protocol.....	37
Status bit.....	52		

NORD DRIVESYSTEMS Group

Headquarters and Technology Centre
in Bargteheide, close to Hamburg

Innovative drive solutions
for more than 100 branches of industry

Mechanical products
parallel shaft, helical gear, bevel gear and worm gear units

Electrical products
IE2/IE3/IE4 motors

Electronic products
centralised and decentralised frequency inverters,
motor starters and field distribution systems

7 state-of-the-art production plants
for all drive components

Subsidiaries and sales partners
in 98 countries on 5 continents
provide local stocks, assembly, production,
technical support and customer service

More than 4,000 employees throughout the world
create customer oriented solutions

www.nord.com/locator

Headquarters:

Getriebebau NORD GmbH & Co. KG

Getriebebau-Nord-Straße 1
22941 Bargteheide, Germany

T: +49 (0) 4532 / 289-0

F: +49 (0) 4532 / 289-22 53

info@nord.com, www.nord.com

Member of the NORD DRIVESYSTEMS Group

